


# LOTUS

## TRAINING


### LOTUS - OMEGA / CARLTON



## **TABLE OF CONTANTS**

LOTUS TRAINING 1ST COVERPAGE
LOTUS TRAINING 2ND COVERPAGE
1.0 GEN. DISCRPTION
1.1 BLOCK DIAGRAMME
1.2 WIRING DIAGRAM AND LEGENDS
1.4 PARAMETERS SENSED VS CONTROLLES
1.5 CATALYTIC CONVERTER
1.5 EFFICIENCY CURVE OF 3-WAY CATALYST
1.5 CATALYTIC CONV. DRAWING
2.1 MAP SENSOR
2.1 MAP PRESSURE SENSOR CHIP
2.1 MAP SENSOR CIRCUIT
2.2 BAROMETRIC PRESSURE SENSOR
2.3 THROTTLE POSITION SENSOR
2.3 TPS CIRCUIT
2.4 COOLANT SENSOR
2.4 CTS CIRCUIT
2.5 MAT SENSOR
2.5 MAT SENSOR CIRCUIT
2.6 EXHAUST OXYGEN SENSOR
2.6 O2 sensor circuit - O2 "COLD SENSOR" -vs- "HOT SENSOR"
2.6 O2-SENSOR CIRCUIT
2.7 VEHICLE SPEED SENSOR
2.8 VEHICLE SPEED SENSOR CIRCIUT
2.9 ESC SENSOR & BOOST CONTROL
2.10 CAM POSITION SENSOR
3.0 WASTEGATE ACTUATOR AND SOLENOID CONTROL
3.1 AIR CONDITIONING CONTROL
3.2 RADIATOR FAN CONTROL
3.3 AUX WATER PUMP, RADIATOR FAN AFTER IGNITION OFF
3.4 EVAPORATIVE EMISSION (CP) CONTROL SYSTEM (EECS)
3.4 EECS / CANISTER FUNCTION
3.5 IDLE AIR CONTROL (IAC) VALVE
3.5 IDLE AIR CONTROL (IAC) VALVE CIRCUIT
4.0 FUEL CONTROL SYSTEM
4.0 FUEL CONTROL SYSTEM 2
4.1 FUEL PUMP CIRCUIT
4.2 FUELING - MODES OF OPERATION
4.3 FUEL CONTROL MODES & STARTING MODE
4.4/4.5 CLEAR FLOOD & RUN MODE
4.6/4.7 TRANSIT FUEL MODES & FUEL CUTOFF MODES
4.8 RUN MODES OPEN LOOP
4.9 CLOSED LOOP FUEL CONTROL
4.99 BATTERY VOLTAGE CORRECTION MODE
5.0 DIRECT IGNITION SYSTEM
5.0 DIRECT IGNITION SYSTEM CIRCUITS
5.1 ELECTRONIC SPARK TIMING MODES
7.0 ELECTRONIC CONTROL MODULE
7.1 ECM CONNECTORS
8.0 DEFAULT & DIAGNOSTIC MODES
8.2 TROUBLE CODES
9.0 CHECKING PROCEDURE EXAMPLE
11.0 TABLE OF CONTENTS

**LOTUS - OMEGA / CARLTÓN TRAINING**



**TRAINING**

**LOTUS - OMEGA / CARLTON**

**THREE DAYS SESSION**

**FIRST DAY**

**SYSTEM & COMPONENT DESCRIPTION  
THEORY OF OPERATION**

**SECOND DAY**

**DIAGNOSTIC CHARTS EXPLANATION**

**THIRD DAY**

**ON CAR DIAGNOSIS WITH "TECH 1" TOOL**

# LOTUS - OMEGA / CARLTON TRAINING

## 1.0 GENERAL DESCRIPTION

The Multipoint Fuel Injection (MPFI) system is used on the LOTUS - OMEGA / CARLTON is a GM fully electronic micro-processor controlled system. The main functions of the system are:

- 1) Fuel Management
- 2) Spark Timing
- 3) Idle (Air) Speed Control
- 4) Turbocharger Wastegate Control

The system provides maximum reduction of tailpipe emissions at optimum performance and driveability.

### 1) FUEL MANAGEMENT

The injectors are controlled by a microprocessor called an "Electronic Control Module" (ECM). It calculates the amount of fuel required by the engine at all conditions from information supplied by a series of sensors.

The engine is equipped with 6 injectors, 1 for each cylinder. The injectors are generally operated (pulsed) in a sequential manner, once each engine cycle. This "sequential" fuel injection follows the firing order of the engine (1, 5, 3, 6, 2, 4). The fuel requirement for each cylinder is delivered by one fuel pulse per engine cycle (*intake, compression, power, exhaust*). The fuel pulse is usually delivered when the intake valves are closed. This improves fuel vapourization, which maximizes power while minimizing emissions.

### 2) SPARK TIMING

This engine has a "Direct Ignition System" (DIS) which is a distributorless type of ignition system. It contains an ignition module, 3 ignition coils, and a crankshaft position (crank angle) sensor. The position sensor generates electrical signals by magnetic interaction with 7 "teeth" machined into the crankshaft torsional balancer. The ignition module receives and processes the signal from the crankshaft position sensor, interfaces with the ECM, and controls the primary current in the ignition coils. Each ignition coil drives two spark plugs.

### 3) IDLE (AIR) SPEED CONTROL


The ECM controls idle speed by means of an "Idle Air Control" (IAC) motor. It provides control of bypass air around the throttle plates. If RPM is lower than desired, the actuator pintle of the motor is retracted and more air diverted around the throttle plates to increase RPM; if RPM is too high the motor is extended.

### 4) TURBOCHARGER WASTEGATE CONTROL


This engine uses two turbochargers. Each turbo has its own conventional wastegate actuator, but both actuators are controlled by one electrical solenoid. The solenoid acts to control boost pressure, and is controlled by the ECM. The ECM uses information from the MAP and knock sensors to control the wastegate solenoid.

# LOTUS - OMEGA / CARLTON TRAINING

## 1.1 BLOCK DIAGRAMME



# 6.1 Circuit Diagram LOTUS CARLTON



6 Circuit Diagram  
6.1 Circuit Diagram LOTUS OMEGA

TACHO	= Interface Connector (Tacho)	M 1	= Starter
X7 Ter. "B"	= A/C Interface Connector (Control Switch)	M 21	= Fuel Pump
X7 Ter. "C"	= A/C Interface Connector (Not used)	M 22	= Hot Soak Water Pump
X7 Ter. "F"	= A/C Interface Connector (Rad Fan Coil)	M 33	= IAC Motor = Idle Air Control Valve
CON 4	= Servotronic Electronic Module Line	P 23	= MAP-Sensor = Manifold Absolute Pressure
FAN	= FAN (Controlled by ECM)	P 24	= BARO-Sensor = Barometric Pressure Sensor
FL 1	= Maxi Fuse 50 Amp.	P 30	= MAT-Sensor = Mass Air Temperature
FLA	= Fuel Pump / Injectors Relay Fuse 20 Amp.	P 31	= CT -Sensor = Coolant Temperature Sensor
FLX	= A/C Fuse 10 Amp.	P 34	= TPS-Sensor = Throttle Position Sensor
FLZ	= 02 / CAM-Sensor Fuse	P 35	= Magnetic Vehicle Speed Sensor
G 1	= Battery	P 46	= Knock Sensor
G 2	= Alternator	P 47	= CAM-Sensor
K 3	= Theft Deterant Relay	S 1	= Ignition Switch
K 6	= Engine Run Relay	S 2	= Idle Pressure Switch (H.P. Line)
K 7	= A/C Clutch Relay	S 3	= H.P. Cut Out Switch (A/C Comp.)
K 31	= Fuel Pump Relay	S 4	= L.P. Cut Out Switch (H.P. Line)
K 32	= Ignition Power Relay	S 5	= High Pressure Switch (A/C Compressor)
K 58	= Hot Soak Pump Relay	X 130	= ALDL-Connector Engine
K 202	= Servotronic Electronic Module	Y 34	= Waste Gate Solenoid
K 203	= Electronic Hydr. Transducer	Y 35	= Charcoal Canister Purge Solenoid
K 204 (K57)	= Fan Relay	Y 36	= Hot Soak Pump Solenoid
K 222	= ECM = Electronic Control Modul	Y 37	= A/C Clutch
L 1	= Oxygen Sensor Left		
L 2	= Oxygen Sensor Right		



# LOTUS - OMEGA / CARLTON TRAINING

Lotus Colors	Vauxhall Colors	Opel Farben
G	Green	Grün
K	Pink	Rosa
N	Brown	Braun
P	Purple	Lila
S	Slade	Grau
U	Blue	Blau
BR	Black Red	Schwarz Rot
BO	Black Orange	Schwarz Orange
GB	Green Black	Grün Schwarz
GR	Green Red	Grün Rot
GY	Green Yellow	Grün Gelb
NB	Brown Black	Braun Schwarz
NW	Brown White	Braun Weiß
OP	Orange Purple	Orange Lila
PK	purple Pink	Lila Rosa
PY	purple Yellow	Lila Gelb
RN	Red Brown	Rot Braun
RY	Red Yellow	Rot Gelb
UG	Blue Green	Blau Grün
UK	Blue Pink	Blau Rosa
US	Blue Slade	Blau Grau
UW	Blue White	Blau Weiß
WB	White Black	Weiß Schwarz
WN	White Brown	Weiß Braun
YS	Yellow Slade	Gelb Grau
YN	Yellow Brown	Gelb Braun
BLG	Black Light Green	Schwarz Hellgrün
GLG	Green Light Green	Grün Hellgrün
LGB	Light Green Black	Hellgrün Schwarz
LGN	Light Green Brown	Hellgrün Braun
LGW	Light Green White	Hellgrün Weiß
LGY	Light Green Yellow	Hellgrün Gelb

DA1D : HOT START  
COOLANT PUMP

LOTUS - OMEGA / CARLTON TRAINING

DA2D : HOT START  
COOLANT PUMP

**1.4 PARAMETERS SENSED VS. PARAMETERS CONTROLLED**

PARAMETERS SENSED	PARAMETERS CONTROLLED							
	FUEL	IDLE SPEED	SPARK TIMING	CANISTER PURGE	BOOST CONTROL	RADIATOR FAN	AIR CONDITION	CHECK ENGINE LIGHT
ENGINE SPEED	X	X	X	X	X		X	X
VEHICLE SPEED		X	X		X	X	X	X
COOLANT TEMP.	X	X	X	X		X	X	X
MASS AIR TEMP.	X	X	X					X
MANIFOLD PRESSURE	X	X	X	X	X			X
BAROMETRIC PRESS.	X	X	X					X
THROTTLE POSITION	X	X	X		X		X	X
BATTERY VOLTAGE	X	X	X			X		X
INJECTOR VOLTAGE	X							X
EXHAUST OXYGEN	X			X				X
ENGINE DETONATION			X		X			X
A/C REQUEST		X				X		
FLYWHEEL POSITION	X		X					
TIME	X	X	X	X	X	X	X	

# **LOTUS - OMEGA / CARLTON TRAINING**

---

## **1.5 CATALYTIC CONVERTER**

Two catalytic converters are used on the Lotus Omega / Carlton.

The catalytic converter is the best way of controlling tailpipe emissions.


The major tailpipe pollutants are hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO<sub>x</sub>).

The LOTUS-OMEGA/CARLTON catalytic converter is a three-way converter. It contains two oxidizing catalysts and a reducing catalyst. A catalyst accelerates a chemical reaction without changing its own properties. The oxidizing catalysts used are platinum and palladium. In the presence of oxygen, they aid in reducing hydrocarbons and carbon monoxide. They add oxygen to HC and CO to convert them to water vapor and carbon dioxide. For this to occur, the fuel injection system must supply an air/fuel ratio of 14.7 to 1 or leaner. If the air/fuel ratio is richer than 14.7 to 1, the converter does a poor job of oxidizing the HC and CO.


The reducing catalyst is rhodium. It speeds up the chemical reaction removing oxygen from NO<sub>x</sub>, thus reducing NO<sub>x</sub> to nitrogen. For this to occur, the air/fuel ratio must be 14.7 to 1 or richer. If the air/fuel ratio becomes leaner than 14.7 to 1, the efficiency of NO<sub>x</sub> conversion is greatly reduced. As seen in the figure on the next page, any air/fuel ratio except 14.7 to 1 greatly reduces the efficiency of one or the other type of catalyst in the converter.

To maintain a high conversion efficiency of HC, CO, and NO<sub>x</sub>, the air/fuel ratio must be maintained as close to 14.7 to 1 as possible.


## PRINCIPLE OF OPERATION 3-WAY CATALYST



**DUAL BED MONOLITH CONVERTER**



LOTUS - OMEGA / CARLTON TRAINING



Probleme Valves  
Fitted on 1991+ Models  
Left over control Valve

**TWO  
CATALYTIC  
CONVERTERS**

## 2.1 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR


The MAP sensor is mounted to the inlet manifold between the throttle bodies, and is connected directly to the manifold using a silicone rubber seal.

The Manifold Absolute Pressure sensor measures the changes in the intake manifold pressure which result from engine load and speed changes, as well as turbo boost. The sensor is a "2 bar" sensor, capable of measuring pressure up to 210 kPa (2 atmospheres).

The sensor uses a silicon chip approximately 3mm square. The chip is attached to a pyrex plate to form a diaphragm approximately 0.25mm thick. Resistors are diffused into the chip to form a wheatstone bridge resistor network. When the chip is sealed to a pyrex plate, a vacuum cavity is formed called a reference vacuum cavity. As pressure or vacuum is applied to the opposite side of the reference cavity, the diaphragm deflects, causing the diffused resistors to change value proportional to the pressure.



The sensor's resistor bridge network is connected to a microcircuit, also part of the sensor. The ECM provides a 5-volt reference voltage to the sensor, as well as a ground. The sensor's internal microcircuit sends an output voltage to the ECM, proportional to the manifold pressure.

Output voltage is approximately 0.5 to 1.0 volts at idle, and 2.5 volts at 105 kPa (1 bar) (atmospheric pressure). Maximum output voltage of 5 volts is available at 210 kPa (2 bar) manifold pressure. The ECM uses this voltage to compute intake manifold pressure.






Delco Electronics manufactures eight different pressure sensors with the same physical appearance. These sensors are not interchangeable and are color coded by the plastic insert in the plug. The sensor plug inserts are keyed so they cannot be used in the wrong system application. The Turbo MAP sensor insert is orange. The Barometric pressure sensor has a blue color sensor plug insert.

# LOTUS - OMEGA / CARLTON TRAINING





# LOTUS - OMEGA / CARLTON TRAINING



# LOTUS - OMEGA / CARLTON TRAINING


## MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT

### Circuit Description:

The Manifold Absolute Pressure (MAP) sensor responds to changes in manifold pressure (engine vacuum or boost). The ECM receives this information as a signal voltage that will vary from about 0.5 to 1.0 volts at idle, when manifold pressure is low (high vacuum), to between 4 and 5 volts at wide open throttle during full boost.

If the MAP sensor fails, the ECM will substitute a "default" MAP value, using the throttle position sensor (TPS) and other sensors to control fuel delivery and spark timing.

■  
P 23



# LOTUS - OMEGA / CARLTON TRAINING

## 2.2 BAROMETRIC (BARO) PRESSURE SENSOR


A barometric pressure signal is used by the ECM to regulate fuel delivery relative to atmospheric pressure, and to accommodate operation of the vehicle at high altitude.

The baro sensor operates in principle very similar to the MAP sensor. The major difference is that the baro sensor has no vacuum hose, and it's 0 to 5 volt operating range is spread out over 105 kPa, as opposed to 210 kPa on the MAP sensor. The BARO sensor is a "1 bar" sensor, capable of measuring pressure up to 105 kPa (1 atmosphere).

The barometer sensor is mounted on a plate, on the left front strut tower. The ECM provides a 5-volt reference voltage to the sensor, as well as a ground. The sensor's internal microcircuit sends an output voltage to the ECM, proportional to the barometric pressure.

Low barometric pressure (high altitude) produces a low sensor signal for a lower fuel requirement. If the barometric sensor should fail, a fixed value would be substituted by the ECM.

Output voltage is approximately 5.0 volts at 105 kPa (1 bar) (*atmospheric pressure at sea level*). The output voltage will reduce at higher altitudes.




# LOTUS - OMEGA / CARLTON TRAINING



## 2.3 THROTTLE POSITON SENSOR

The throttle positon sensor is a potentiometer fitted to the front end of the throttle spindle, on the front throttle body. See picture below D 2161 "A". The ECM supplies a 5 volt refereance voltage and a ground circuit to the sensor, and by monitoring the sensor output voltage on a returning signal line, the ECM is able to determine throttle position. TPS is used as one of the inputs to determine fuel requirements.

With the throttle closed, the TPS output is low ( typical 0.25 volt), but increases as the throttle is open until at wide open throttle output voltage is about 5.0 volts. This signal is used by the ECM for fuel control and for many of the ECM controlled outputs. If a fault is detected and a trouble code set, the ECM will substitute an artificial default value for the TPS signal based on RPM, to enable the vehicle to " limp home". This mode may result in a high idle speed.




# LOTUS - OMEGA / CARLTON TRAINING




ECM


TPS



2-15-90  
LS 9242-15



## THROTTLE POSITION SENSOR (TPS) CIRCUIT



### Circuit Description:

The ECM applies a "reference voltage" of 5 volts on J2B5, and supplies a ground circuit on J2B16.

The throttle position sensor (TPS) sends back a voltage signal that changes relative to the throttle opening. Signal voltage will vary from about 0.2 to 0.3 volt at idle to about 5.0 volt at wide open throttle (WOT).

The TPS signal is one of the inputs used by the ECM for fuel control and for most other ECM controlled outputs.

# LOTUS - OMEGA / CARLTON TRAINING



## 2.4 COOLANT TEMPERATURE SENSOR (CTS)

The coolant temperature sensor (CTS) is a thermistor mounted in the coolant stream. On the Lotus Omega / Carlton, the CTS is mounted in the thermostat housing in front of the temp. gauge sender. The thermistor changes its resistance with changes of coolant temperature. Low temperature produces a high resistance, approximately 25,000 ohms at -20°C. As coolant temperature increases, sensor resistance decreases to about 185 ohms at 100°C.

The voltage drop across the coolant sensor varies from 0 to 5 volts. This voltage, measured at the ECM, will decrease as coolant temperature increases; therefore, disconnecting the coolant sensor simulates a cold engine, and shorting across the sensor simulates a hot engine.


The circuit operation for the Coolant and MAT sensors are the same. The way the ECM interprets the voltage is also the same for each, although each sensor's signal is used for different functions by the ECM.

Both the coolant and MAT temperature sensors are negative temperature coefficient thermistors. As they become hotter, their resistance becomes less.




VOLTAGE DIVIDER NETWORKS USING 2 RESISTORS AND A 5 VOLT SOURCE.

# LOTUS - OMEGA / CARLTON TRAINING





## COOLANT TEMPERATURE SENSOR CIRCUIT



### Circuit Description:

The coolant temperature sensor uses a thermistor to control the signal voltage at the ECM. The ECM applies a voltage on J2B9 to the sensor. When the engine is cold the sensor (thermistor) resistance is high, therefore ECM terminal J2B9 voltage will be high.


As the engine warms, the sensor resistance becomes less, and the voltage drops. At normal engine operating temperature, the voltage will measure about 1.5 to 2.0 volts at ECM terminal J2B9.

See MAT sensor circuit for approximate temperature -to- resistance values.

Coolant temperature is one of the inputs used to control:

- Fuel delivery
- Engine Spark Timing (EST)
- Idle Air Control (IAC)
- Evaporative Emission Control (Canister Purge) System (EECS)
- Radiator Fan
- Air conditioner compressor clutch
- Auxiliary water pump

## THROTTLE POSITION SENSOR (TPS) CIRCUIT



### Circuit Description:

The ECM applies a "reference voltage" of 5 volts on J2B5, and supplies a ground circuit on J2B16.

The throttle position sensor (TPS) sends back a voltage signal that changes relative to the throttle opening. Signal voltage will vary from about 0.2 to 0.3 volt at idle to about 5.0 volt at wide open throttle (WOT).

The TPS signal is one of the inputs used by the ECM for fuel control and for most other ECM controlled outputs.



## 2.4 COOLANT TEMPERATURE SENSOR (CTS)

The coolant temperature sensor (CTS) is a thermistor mounted in the coolant stream. On the Lotus Omega / Carlton, the CTS is mounted in the thermostat housing in front of the temp. gauge sender. The thermistor changes its resistance with changes of coolant temperature. Low temperature produces a high resistance, approximately 25,000 ohms at -20°C. As coolant temperature increases, sensor resistance decreases to about 185 ohms at 100°C.

The voltage drop across the coolant sensor varies from 0 to 5 volts. This voltage, measured at the ECM, will decrease as coolant temperature increases; therefore, disconnecting the coolant sensor simulates a cold engine, and shorting across the sensor simulates a hot engine.

The circuit operation for the Coolant and MAT sensors are the same. The way the ECM interprets the voltage is also the same for each, although each sensor's signal is used for different functions by the ECM.

Both the coolant and MAT temperature sensors are negative temperature coefficient thermistors. As they become hotter, their resistance becomes less.




VOLTAGE DIVIDER NETWORKS USING 2 RESISTORS AND A 5 VOLT SOURCE.

## 2.5 MANIFOLD AIR TEMPERATURE (MAT) SENSOR


The Manifold Air Temperature (MAT) sensor is fitted into the intake manifold, above the front cylinder runner. The ECM uses this signal in conjunction with others to calculate air density and the appropriate fuel delivery for both starting and running. The MAT sensor is also used in determining when to operate the auxiliary water pump and radiator fan after engine shutdown.

The MAT sensor is a thermistor (a resistor which changes value with temperature) similar to the coolant temperature sensor. (See coolant sensor for circuit operation.) Low temperature produces a high resistance (100,000 ohms at minus 40°C) while high temperature causes low resistance (185 ohms at 100°C). The ECM supplies, through an internal resistor, a 5 volt signal to the MAT sensor. By measuring the resulting circuit voltage it is able to calculate the manifold air temperature.

Low air temperature produces a high sensor resistance for a higher fuel requirement.




COOLANT and MAT SENSOR TEMP. TO RESISTANCE VALUES (APPROXIMATE)	
° Centigrade	OHMS
110°	90
100°	185
90°	225
70°	450
40°	1,750
20°	3,400
0°	10,000
-20°	25,000
-40°	100,000



## MANIFOLD AIR TEMPERATURE (MAT) SENSOR CIRCUIT

### Circuit Description:

The MAT sensor uses a thermistor to control the signal voltage to the ECM. The ECM applies a voltage of about 5 volts on CKT J2B21 to the sensor. When the air is cold, the sensor (thermistor) resistance is high, therefore, the ECM terminal "J2B21" voltage is high. As the air warms, the sensor resistance becomes less, and the voltage drops. As the incoming air gets warmer, the sensor resistance decreases, causing ECM terminal "J2B21" voltage to decrease.



## 2.6 EXHAUST OXYGEN (O<sub>2</sub>) SENSORS

The Lotus - Omega / Carlton engine uses two oxygen sensors; one for the front three cylinders, and a second sensor for the rear three cylinders. Both sensors contain an electric heating element, to ensure fast warmup of the sensors, and thus a faster transition to closed loop fuel control.

The oxygen sensors monitor the oxygen content in the exhaust. The oxygen sensor consists of zirconia electrolyte between two platinum plates. Zirconia comes from zirconium, which is a basic chemical element. When zirconia comes in contact with oxygen, it becomes an electrical conductor (electrolyte). A chemical reaction takes place on the platinum plates, causing oxygen ions to build up on the platinum plates (an ion is an atom or molecule with too many or too few electrons). The oxygen ion has two more electrons than a normal oxygen atom, so the ions have a negative electrical charge.


The oxygen sensor is installed so that exhaust gas is passed through louvers in the bottom of the oxygen sensor. One plate is in contact with the exhaust gas side and the other plate is in contact with outside air. Outside air enters the top of the oxygen sensor and flows down the center of the sensor to the inner chamber.

Oxygen ions build up on both platinum plates. The platinum plate on the air-reference side of the sensor has more oxygen ions than the platinum plate on the exhaust gas side of the sensor. Therefore, the platinum plate on the air-reference side is electrically negative, and the platinum plate on the exhaust gas side of the sensor is positive. A difference in electrical potential or voltage is developed between the two platinum plates. The voltage across the platinum plates ranges from approximately 100 millivolts to 900 millivolts, dependent on the oxygen content of the exhaust.


If the air/fuel mixture is rich, few oxygen ions appear in the exhaust gas side of the sensor. The platinum plate on the exhaust gas side of the sensor becomes more positive. The electrical charge on the platinum plate at the air-reference side does not change; therefore, the voltage difference between the two platinum plates increases.

When air/fuel mixture is lean, a large number of oxygen ions will appear on the exhaust side of the oxygen sensor. This makes the platinum plate on the exhaust gas side of the sensor more negative. The voltage difference between the two platinum plates decreases.

Therefore, if the air/fuel mixture is rich, the oxygen sensor voltage is high. If the air/fuel mixture is lean, the oxygen sensor voltage is low. The ECM measures the voltage difference between the platinum plates to determine whether the air/fuel mixture is rich or lean.




**LOTUS - OMEGA / CARLTON TRAINING**







**LOTUS - OMEGA / CARLTON TRAINING**



LOTUS - OMEGA / CARLTON TRAINING




**PRINCIPLE OF OPERATION 3-WAY CATALYST**




IS 0431  
3-5-86

# OXYGEN SENSOR VOLTAGE OUTPUT CHARACTERISTIC CURVE




## OXYGEN SENSOR CIRCUIT





### Circuit Description:

The ECM supplies a voltage of about .45 volt between terminals "J3E14" and "J2B4". (If measured with a 10 megohm digital voltmeter, this may read as low as .32 volt.) The O<sub>2</sub> sensor varies the voltage within a range of about 1 volt if the exhaust is rich, down through about .10 volt if exhaust is lean.


The sensor is like an open circuit and produces no voltage when it is below 360°C (600° F). An open sensor circuit or cold sensor causes "Open Loop" operation. A not functional sensor heater causes a delayed "Closed Loop" operation.




# COLD SENSOR



# HOT SENSOR




When the sensor is hot, the 450mV bias voltage goes to ground through the sensor's low internal resistance




**O<sub>2</sub> SENSOR BIAS VOLTAGE**

# LOTUS - OMEGA / CARLTON TRAINING






# LOTUS - OMEGA / CARLTON TRAINING




**O<sub>2</sub> sensor voltage output  
during closed loop operation  
(steady engine load)**

# LOTUS - OMEGA / CARLTON TRAINING




# LOTUS - OMEGA / CARLTON TRAINING



**O<sub>2</sub> SENSOR OUTPUT VOLTAGE**  
**CODE 44 - lean exhaust indication**

64

# LOTUS - OMEGA / CARLTON TRAINING




O<sub>2</sub> SENSOR OUTPUT VOLTAGE  
CODE 45 - rich exhaust indication


65

4

# LOTUS - OMEGA / CARLTON TRAINING




## O<sub>2</sub> SENSOR operating voltages



## **O<sub>2</sub> SENSOR VOLTAGE OUTPUT**

**SENSOR COATED (CONTAMINATED) ON EXHAUST GAS SIDE**



**O<sub>2</sub> SENSOR OUTPUT VOLTAGE**  
with **ATMOSPHERIC VENT PLUGGED**


## 2.7 VEHICLE SPEED SENSOR (V.S.S.)

Vehicle speed information is supplied to the ECM by the vehicle speed sensor which is a permanent magnet generator mounted on the transmission. The generator produces a pulsing AC voltage whenever vehicle speed is over about 3 mph (5 Km/h) and which increases in value and frequency with increasing vehicle speed.


The VSS signal information is used by the ECM to assist in the control of:

- Idle Air Control
- Canister Purge Control
- Air Conditioner Clutch Control
- Electric Radiator Fan
- Turbo Wastegate Control
- SETPOINTRONIC
- SPEEDO





VEHICLE  
SPEED  
SENSOR




# LOTUS - OMEGA / CARLTON TRAINING

## VEHICLE SPEED SENSOR CIRCUIT

### Circuit Description:

Vehicle speed information is provided to the ECM by the vehicle speed sensor (VSS) which is a permanent magnet (PM) generator that is mounted in the transmission. The PM generator produces a pulsing voltage whenever vehicle speed is over about 3 mph, (5 Km/h). The AC voltage level and the number of pulses increases with vehicle speed. The ECM then converts the pulsing voltage to Km/h which is used for calculations and the interpreted Km/h can be displayed with Tech 1. Output of the generator can also be seen by using a digital voltmeter on the AC scale while rotating the generator.



## 2.9 ELECTRONIC SPARK CONTROL (ESC) & WASTEGATE ACTUATOR SOLENOID CONTROL

This system comprises an engine "knock" sensor mounted below the intake manifold in the cylinder block, a turbo boost control solenoid valve, and an ESC module which is incorporated into the ECM "Mem-Cal" cartridge.


The ignition timing required for optimum performance can lead, under certain operating conditions, to detonation of the fuel mixture in the combustion chamber, causing excessive heat and pressures and a characteristic "knocking" noise. If allowed to continue unchecked, major engine damage can occur. The ESC system allows the engine to adhere as closely as possible to the optimum ignition timing and turbo boost settings without a damaging level of detonation.

When the knock sensor detects the onset of detonation, the ECM both retards ignition and reduces turbo boost pressure to a safe level, and then progressively advances ignition and raises boost until detonation is again detected and the cycle repeats.




### KNOCK SENSOR

The knock sensor is mounted in the cylinder block, and is able to identify the detonation "knocking" noise and produce an AC output voltage which increases with the severity of the knock. The ECM monitors this signal and adjusts the electronic spark timing (EST) and boost pressure as necessary to reduce detonation to a safe level.

WASTEGATE SOLENOID VALVE and KNOCK SENSOR



# LOTUS - OMEGA / CARLTON TRAINING



# LOTUS - OMEGA / CARLTON TRAINING

## ELECTRONIC SPARK CONTROL (ESC) & BOOST CONTROL

The wastegate actuator contains an internal spring to preload the wastegate closed. Normally, boost pressure is controlled by applying intake manifold pressure through a small hose to the wastegate actuator. The actuator is constructed with spring pressure applied to one side of its diaphragm, and the opposite side of the diaphragm exposed to manifold pressure through the connecting hose. At 1.55 bar (8 psi boost), manifold pressure would overcome spring pressure, and the diaphragm would begin to move, causing the wastegate to open. If the hose is either blocked or removed from the actuator, or a leak exists in the hose, the wastegate would not open, and engine protection would be achieved only by the overboost protection in the ECM. When the ECM detects a manifold pressure of 1.98 bar (from the MAP sensor), the ECM will discontinue all fuel injection pulses until manifold pressure drops below 1.6 bar.

Inserted into the hose, between the actuator and the compressor-side of the turbocharger, is a normally-open, ECM-controlled solenoid. The solenoid controls how much manifold pressure is directed to the wastegate actuator. Recall that if unrestricted manifold pressure is applied to the actuator, boost pressure would only achieve 1.55 bar. (This would be the case if the solenoid were to become electrically disconnected.) In order to achieve higher controlled boost pressures, the ECM pulses the solenoid, to close off the passageway, effectively raising the boost pressure above 1.55 bar. The ECM pulses the solenoid many times each second with a constant-frequency square wave, but varying the pulsewidth. I.e., duty cycle, or proportion of time the solenoid is pulsed shut. This controls the amount of "extra" boost that may be developed.

When TPS > 80%, if the knock sensor detects the onset of detonation, the ECM alters the duty cycle of the solenoid to lower the amount of boost until detonation ceases. This "WASTE GATE solenoid duty cycle" is stored in the PROM/MEMCAL of the ECM.

The "WASTE GATE BLOCK LEARN MEMORY" is a portion of ECM memory used to make long-term corrections to desired boost pressure. This correction is to compensate for small tolerances and/or normal aging of parts in each of the various system components.


The ECM has a memory portion of 16 cells to modify the above mentioned tolerances.

For example: If the MAP-Sensor detects a boost pressure greater or less than stored on the PROM/MEMCAL for this engine speed and load, the concerning WASTE GATE BLOCK LEARN MEMORY cell will be updated. Following this update, the WASTE GATE SOLENOID duty cycle will be modified to prevent under- or overboost.


Attention: The content of the WASTE GATE BLOCK LEARN MEMORY cell is not identical to the WASTE GATE SOLENOID VALVE duty cycle. The content will only be used to modify this WASTE GATE SOLENOID VALVE duty cycle.

Content of the WASTE GATE BLOCK LEARN MEMORY cells below only for example:


(+ 4%) cell 09	(+ 3%) cell 10	(+ 2%) cell 11	(+ 1%) cell 12	(0%) cell 13	(-1%) cell 14	(-2%) cell 15	(-4%) cell 16	Engine speed --->
4000-4500	4500-5000	5000-5500	5500-6000	6000-6500	6500-7000	7000-7500	7500-8000	RPM
(0%) cell 01	(-6%) cell 02	(+ 1%) cell 03	(-2%) cell 04	(-3%) cell 05	(+ 5%) cell 06	(+ 6%) cell 07	(+ 5%) cell 08	Engine speed --->
0-500	500-1000	1000-1500	1500-2000	2000-2500	2500-3000	3000-3500	3500-4000	RPM




Note that because the ECM monitors boost pressure via the MAP sensor, maximum boost pressure is controlled to absolute values which are independent of atmospheric pressure. For this reason, the maximum readings of the boost gauge in the instrument panel will tend to rise with increasing altitude and decreasing atmospheric pressure.




# BOOST CONTROL



Boost Control Line Open




Boost Control Line Cut Off



Note that because the ECM monitors boost pressure via the MAP sensor, maximum boost pressure is controlled to absolute values which are independent of atmospheric pressure. For this reason, the maximum readings of the boost gauge in the instrument panel will tend to rise with increasing altitude and decreasing atmospheric pressure.



**LOTUS - OMEGA / CARLTON TRAINING**




**ADJUSTMENT  
POINT**

See Checking  
Procedures

**WASTEGATE  
SOLENOID**

**ACTUATORS**



WASTEGATE  
Y34


HEAVY Y36

## 2.10 CAM POSITION SENSOR

### Circuit Description:

The cam position sensor is used to allow the ECM to calculate when number 1 cylinder is at the top of its stroke (TDC) AND on compression. This signal is used by the ECM to "sequence" the fuel injectors. This engine uses sequential fuel injection. That means the fuel injectors follow the firing order of the engine. (1, 5, 3, 6, 2, 4)

Each fuel injector "spray" at closed intake valves. This is to improve vapourization of the fuel, which improves performance and reduces emissions. In order to accomplish this, the ECM; must know the camshaft position, in order to properly sequence the injector firing order.




~~SCHEMATIC~~  
~~BACKFIRE~~

~~SCHEMATIC~~  
SURGING  
CODE 31

CAM ANGLE FAILURE  
~~SENSOR~~ SENSOR  
UNDER BURN

P.T.O

**LOTUS - OMEGA / CARLTON TRAINING**



**CAM SENSOR  
CONNECTOR**

BACK FIREING,  
SINGING,  
FAILURE,  
UNDER BARRY.

CODE 31.

## 3.1 AIR CONDITIONING

When the air conditioning is switched on at the instrument panel, a 12 volt signal voltage is sent through two pressure switches to the ECM. The two pressure switches prevent the compressor from operating if the R-12 refrigerant is either inadequate (*low pressure cutout switch, located in the high pressure line*), or if the refrigerant pressure becomes too high (*high pressure cutout switch, located in the A/C compressor*). If both switches are closed, the ECM receives an A/C request signal.

When the ECM receives the request signal, it will first reposition the Idle Air Control (IAC) valve, to compensate for the additional load placed on the engine by the A/C compressor. Then the ECM will energize the A/C control relay.

This air conditioning system has a "idle pressure" switch connected to the ECM. The switch is installed in the high pressure refrigerant line. This idle pressure switch has the possibility of acting as an additional input to the ECM, to alter idle speed during certain A/C system operating conditions, but presently the ECM does not use it.


If the A/C was off and is just being turned on, some engine operating conditions will override the A/C request signal and prevent the the air conditioning from being operated. These include:

- Engine speeds above 5000 RPM
- High throttle openings (>83% TPS) to make full engine power available
- Vehicle speed has been above 211 Km/h for more than 3 minutes
- Coolant temperature more than 117°



If the A/C is presently operating, certain engine operating conditions will de-energize the A/C compressor. These include:

- Throttle wide open (>99% TPS)
- Coolant temperature above 124°
- Vehicle speed has been above 211 Km/h for more than 3 minutes.  
If de-energized due to high vehicle speed, speed must remain below 211 Km/h for at least 3 minutes for the A/C to be turned on again.

LOTUS - OMEGA / CARLTON TRAINING



**LOTUS - OMEGA / CARLTON TRAINING**



## 3.2 RADIATOR FAN CONTROL

On the Lotus - Omega / Carlton, the engine is equipped with an engine driven radiator fan. Also used is an electric fan, placed in front of the A/C condenser coil, which is in front of the radiator. The electric radiator fan is a "pusher" fan, and when energized, will aid in cooling both the coolant radiator and A/C condenser.


The ECM controls the fan relay. When the relay is energized, it's switch contacts close to provide power to the fan directly from the battery, and the fan will run.

The electric radiator fan relay is energized by the ECM when the engine is running by these conditions:

- Any malfunction codes are "active" (Check Engine Light ON with engine running)
- A/C is on and vehicle speed less than 8 Km/h. <sup>57.44</sup> *5.7 km/h / 3.6 mph*
- Coolant temperature more than 99°. If energized due to coolant temperature, temp. must drop below 96° for fan to be de-energized.

A high refrigerant pressure switch, located in the A/C compressor, can also energize the fan relay directly, anytime A/C refrigerant pressure is high. This switch is not connected to the ECM, only to the relay.

**LOTUS - OMEGA / CARLTON TRAINING**





## **3.3 AUXILIARY WATER PUMP and RADIATOR FAN OPERATION AFTER IGNITION IS OFF**

A new feature of the Lotus - Omega / Carlton engine management system is that the ECM has the ability to operate an auxiliary water pump and radiator fan even AFTER the ignition is turned OFF. The ECM monitors coolant temperature and manifold air temperature to determine whether or not to run the auxiliary water pump and electric radiator fan after the ignition is off. The calibration of the ECM allows the auxiliary pump and radiator fan to be energized independently, during "engine not running" operation.

The auxiliary water pump is a small electric water pump, mounted on a plate that is secured to the right front strut tower. Its purpose is to circulate coolant through the engine, turbochargers, and radiator after the engine is stopped if high engine temperatures are present. A solenoid is connected with the aux. pump to block coolant flow to the heater core during aux. pump operation. The solenoid controls vacuum from the vacuum reservoir tank, to close the heater core water valve.

**AUXILIARY WATER PUMP** relay will be energized after the ignition is OFF if:

- Coolant temperature  $>92^{\circ}$  (*Runs until coolant temp.  $< 90^{\circ}$* ),  
-OR-
- Manifold air temperature exceeds  $116^{\circ}$  (*Runs until MAT temp.  $< 106^{\circ}$* ),  
-OR-
- Radiator fan has been energized.

If both the CTS and MAT sensors indicate that temperatures are below the listed values, and the radiator fan is not energized, the pump will be de-energized.

**RADIATOR FAN** relay will be energized after the ignition is OFF if:

- Coolant temperature  $>97^{\circ}$   
-OR-
- Manifold air temperature  $>113^{\circ}$ .


If both the CTS and MAT sensors indicate that temperatures are below the listed values, the fan will be de-energized.

Maximum continuous "ignition off" running time for the fan or aux. water pump is 15 minutes.

If neither the fan nor the aux. pump is running and the ignition is off, the ECM will remain "alive" or "powered up" for an additional 10 minutes to monitor the coolant and manifold temperatures. If either temperature raises above the listed values, the fan or pump can be re-energized again until temperatures are reduced. The 10 minute timer in the ECM is reset to 0 each time the fan or pump is re-energized.

If after 10 minutes the coolant temperature and manifold air temperature remain below the listed values, the ECM will "power down", or "go to sleep".

# LOTUS - OMEGA / CARLTON TRAINING




LOTUS - OMEGA / CARLTON TRAINING

CHARGE COOLER  
FILL POINT

CHARGE COOLER  
WATER PUMP

NO MORE THAN  
30°-70 60°-75MP

Self Sealing




LOTUS - OMEGA / CARLTON TRAINING

HOT SOAK  
WATER  
PUMP

WATER COOLET OVER FAN

HEATER  
CORE  
WATER  
VALVE



LOTUS - OMEGA / CARLTON TRAINING

PERFECT MATCH VALVE  
BY WORKING WAY

?

WATER GATE RIL  
PIPE SIZE


SOLENOID,  
AUX.

WATER  
PUMP

HOT SOAK  
(AUXILIARY)  
WATER PUMP  
DISPLAY

WATER PUMP  
(HOT SOAK)  
AUX.

Shown horizontal /  
Production unit  
mounted  
vertically ↓



\* IF FOUL STAN RETRAV (NOT IN) CANISTER MUST BE REPLACED )

# LOTUS - OMEGA / CARLTON TRAINING

## 3.4 EVAPORATIVE EMISSION (CANISTER PURGE) CONTROL SYSTEM (EECS)

The system uses a charcoal canister to absorb fuel vapours from the fuel tank when the vehicle is not operating. When the engine is running, the fuel vapour is purged from the charcoal by a flow of air through the unit, which is then consumed in the normal combustion process.

### VAPOUR CANISTER

This is located above the rear axle, close to the right rear tyre.

Fuel vapour from the fuel tank filler neck is routed via a roll-over-valve (to prevent fuel spillage if the car is inverted) to the canister port labelled "tank". Any liquid fuel collects in a reservoir in the bottom of the canister to protect the integrity of the carbon bed above.

Ambient air enters the canister through an air tube in the top and mixes with the vapour before being drawn through the controlling solenoid valve into the intake manifold.

TPS - 2-3%  
 COOLANT 80°  
 VSS 35 M.P.H  
 CONTROL SYSTEM


TPS - COOLANT TEMP 2°  
 VSS

A solenoid valve is mounted on top of the canister, and controls the purge line. It uses pulse width modulation to control purge. This signal is supplied by the ECM which opens and closes the normally closed solenoid valve many times a second.

Under cold engine or idle conditions, the solenoid valve remains closed and no purging takes place. The ECM energizes the solenoid valve and allows purging when:


- 1) the engine is warm 80°
- 2) the engine has been running for a specified period of time.

The pulse width of the solenoid valve signal is controlled by the ECM, which uses various sensors, including the exhaust oxygen (O<sub>2</sub>) signal to determine the quantity of vapour which may be fed into the engine under the operating conditions at that time.




LOTUS - OMEGA / CARLTON TRAINING

EVAPORATIVE  
EMISSION  
CANISTER



CANISTER





# LOTUS - OMEGA / CARLTON TRAINING


## CANISTER FUNCTION

The inverted function canister pictured is a solenoid-controlled, double dip tube model. Vapours are vented into that canister through the larger, outside dip tube. They travel to the bottom of the canister and are there released into the carbon.

Purge air enters the canister at the top, is pulled down through the carbon, then up the smaller, inside dip tube.

Another feature which is being included on this canister is a trap for liquid fuel. While liquids are not supposed to enter a canister, they sometimes do. A canister becomes "loaded" with the liquid and loses its ability to trap vapours.

The trap collects the liquid fuel, and when the canister is purged, the purge air flow vaporizes the liquid. A fine mesh screen at the bottom of the dip tube acts as a wick, holding the liquid so it is more effectively vaporized and removed.



# LOTUS - OMEGA / CARLTON TRAINING

## 3.5 IDLE AIR CONTROL (IAC) VALVE

The purpose of the idle air control (IAC) valve assembly is to control engine idle speed, while preventing stalls due to changes in engine load.

The IAC valve is mounted on the top of the intake manifold and controls an airway between the upstream side of the throttle body (to which it is connected by hose) and an air rail which connects with each of the six intake ports. By moving a conical valve (called a pintle) IN (to decrease air flow) or OUT (to increase air flow), a controlled amount of air is allowed to bypass the throttle plate. If rpm is too low, more air is bypassed around the throttle valve to increase rpm. If rpm is too high, less air is bypassed to decrease rpm.

The electronic control module (ECM) moves the IAC valve in small steps, called "Counts". These can be measured by the "Tech 1" tool.

During idle, the proper position of the IAC valve is calculated by the ECM, based on battery voltage, coolant temperature, engine load, and engine rpm. If the rpm drops below specification, and the throttle valve is closed, the ECM senses a near stall condition and calculates a new valve position to prevent stalls.

The ECM "learns" the proper positioning of the IAC valve and retains this information in memory. This means that disconnecting power to the ECM can result in incorrect idle control after start. Reset of the IAC is necessary. See TECH 1 MODE F7: ECM Reset SUBMODE F0: IAC Motor

If the IAC valve is disconnected and reconnected while the engine is running, the resulting idle rpm may be wrong, and resetting of the IAC valve will be required.

The ECM resets the IAC valve by seating it (all the way out) to establish the zero count position and then backing it in to the desired position.

This occurs:


- Each time the ignition is turned OFF. The ignition must be off for at least 10 seconds for the reset maneuver to be completed.

170 When servicing the IAC valve, it should only be disconnected or connected after the ignition has been "OFF" for at least 10 seconds. This allows time for the ECM to move the IAC valve to the 80 count position where it is "parked" while the ignition is "OFF". If this procedure is not followed, the ECM will lose track of IAC valve position resulting in starting or idle control problems.

10 FAULT CODE

INTAKE MANIFOLD

IAC




## IDLE AIR CONTROL (IAC) VALVE

### IAC CIRCUIT

The idle air control stepper motor consists of a housing with two coils. The rotor on the inside consists of permanent magnets. The rotary motion of the 24 pole rotor with alternating north and south poles is converted to a linear motion with the aid of a worm gear.

The ECM closes the coil circuits alternately. This results in a torque acting on the rotor, which then turns in a specific direction.



### IAC TEST

Use TECH 1 MODE F5: Actuator Test  
SUBMODE F4: IAC Motor

See also Checking Procedure Table 5

# LOTUS - OMEGA / CARLTON TRAINING

M P F 1 FUEL SYSTEM

## 4.0 FUEL CONTROL SYSTEM

AND PULSATOR

### FUEL PUMP

The fuel pump is a roller vane type, high pressure electric pump mounted ~~submerged within the fuel tank~~. The pump supplies fuel at a pressure of 211- 379 kPa ??? (30.5 - 55 psi) dependent on operating conditions, through an in line filter to the fuel rail assembly. A fuel strainer is attached to the fuel pump inlet line and prevents dirt particles from entering the fuel line and tends to separate water from the fuel.

The pump is able to deliver 4 - 5 times the engines maximum requirement, so that fuel is constantly circulated through the fuel rail, and via the fuel pressure regulator, back to the tank. This fuel circulation helps avoid excessive fuel temperature with consequent risk of vapour locks.

When the ignition is switched on, the ECM energizes the fuel pump which will continue to run for as long as the ECM receives ignition pulses from the ignition module (engine cranking or running). ~~(If no ignition pulses are received, the ECM switches off the pump either 2 seconds (approx.) after the ignition was switched on, or about 10 seconds after a stall.~~

LATER

### FUEL RAIL + PRESSURE REGULATOR

The fuel rail receives fuel ~~at its forward end~~ (from the in-line filter) and supplies all six injectors with fuel, the pressure of which is controlled by the fuel pressure regulator ~~fitted to the rear end of the rail~~. The pressure regulator assembly is a diaphragm operated relief valve with fuel pump pressure acting on one side of the diaphragm, and regulator spring pressure and intake manifold pressure on the other. The function of the regulator is to maintain a constant pressure differential across the injectors at all times. i.e. a constant difference between fuel pressure supplied to the injector, and inlet manifold pressure at the injector nozzle. By using an inlet manifold pressure signed to supplement regulator spring pressure in the valve, the valve is able to regulate fuel supply pressure in accordance with engine load. The pressure regulator is not adjustable and is serviced as a complete assembly.

### FUEL INJECTORS

The port fuel injector assembly is a solenoid-operated device, controlled by the electronic control module (ECM), that meters pressurized fuel to a single engine cylinder. The ECM energizes the *high impedance (12.2Ω @ 20°C)* solenoid to open a normally closed ball valve. and through a recessed flow director plate at the injector outlet. The director plate has six machined holes that control the fuel flow, generating a conical spray pattern of finely atomized fuel at the injector tip. Fuel from the tip is directed at the intake valve, causing it to become further atomized and vaporized before entering the combustion chamber.


NEW O. RINGS TO BE FITTED ON INJECTORS WHEN REMOVED  
SEALS

# LOTUS - OMEGA / CARLTON TRAINING


## FUEL CONTROL SYSTEM CONTINUED

The ECM uses six injector driver circuits. Each circuit pulses the injector sequentially once every two crankshaft revolutions, with all of the fuel necessary for each cylinders combustion delivered by each injector pulse.


The ECM receives an engine speed, crankshaft position, and camshaft position signal six times per engine revolution from the ignition module, and uses these to trigger the injector timing sequence. To ~~synchronize the engine revolution with~~ the fuel injector timing sequence, a camshaft signal is necessary.




# LOTUS - OMEGA / CARLTON TRAINING



LOTUS - OMEGA / CARLTON TRAINING










# LOTUS - OMEGA / CARLTON - TRAINING


ADVICE REGARDING VALVE BUILT INTO PUMP



# LOTUS - OMEGA / CARLTON TRAINING



- 1 SOLENOID ASSEMBLY
- 2 SPACER & GUIDE ASSEMBLY
- 3 CORE SEAT
- 4 BALL VALVE
- 5 SPRAY TIP
- 6 DIRECTOR PLATE
- 7 SPRAY HOUSING
- 8 CORE SPRING
- 9 SOLENOID HOUSING
- 10 SOLENOID
- 11 FUEL INLET FILTER



- 1 MPFI INJECTOR (TOP VIEW)
- A PART NUMBER IDENTIFICATION
- B BUILD DATE CODE
- C MONTH 1-9 (JAN-SEPT)  
O,N,D (OCT,NOV,DEC)
- D DAY
- E YEAR



# LOTUS - OMEGA / CARLTON TRAINING

## 4.1 FUEL PUMP CIRCUIT

### Circuit Description:

When the ignition switch is turned "ON", the electronic control module (ECM) turns "ON" the in-tank fuel pump. It will remain "ON" as long as the ECM is receiving ignition reference pulses from the Direct Ignition module (DI).  
If there are no reference pulses, the ECM will shut "OFF" the fuel pump about 2-3 seconds after key "ON", ~~or about 10 seconds after reference pulses stop.~~

See also Checking Procedure Test step 02.



## **4.2 MODES OF FUEL SYSTEM OPERATION**

**STARTING MODE**

**CLEAR FLOOD MODE**

**RUN MODES**

**- OPEN LOOP MODE**

**- CLOSED LOOP MODE**

**- ACCELERATION MODE**

**- DECELERATION MODE**

**- BATTERY VOLTAGE CORRECTION MODE**

**- FUEL CUT-OFF MODE**


## FUEL CONTROL MODES

The ECM uses voltage inputs from the sensor to determine how much fuel to deliver to the engine. The fuel may be delivered in any one of several different "modes" with the ECM controlling which mode is appropriate according to the readings it receives from the sensors at that particular time.

### 4.3 STARTING MODE

When the ignition is first turned on, the ECM turns on the fuel pump relay for two seconds to pressurize the system ready for starting. The ECM also checks the coolant temperature sensor and throttle position sensor readings and determines the appropriate air/fuel ratio for starting. This ranges from approximately 0.8 : 1 at minus 40°C to 16.8 : 1 at 104°C engine coolant temperature.

The ECM controls the quantity of fuel delivered by changing the injector pulse width i.e. length of time the injector is energised and opened.



## **4.4 CLEAR FLOOD MODE**

Provision is made for clearing a flooded engine as follows:

If the throttle is held fully open and the engine cranked, the ECM will decrease injector on time for as long as engine speed is below approx. 600 rpm. If throttle opening becomes less than approx. 70% the ECM returns to the starting mode.

## **4.5 RUN MODE**

Above 600 rpm the ECM switches to RUN MODE.

The amount of fuel supplied depends:

- engine speed
- manifold air pressure
- atmospheric pressure (baro)
- throttle position
- coolant temperature

# LOTUS - OMEGA / CARLTON TRAINING

## 4.6 TRANSIT FUEL MODES

### DECELERATION FUEL CUTOFF

The purpose of the decel fuel cutoff function is to remove fuel from the engine during deep deceleration conditions.

# 12 M.P.M  
TPS 4"  
TPS 90  
MAP 30 KPa  
RPM 1000

### DECELERATION ENLEANMENT

During light deceleration injector pulse width is decreased depending on change of throttle position, change of MAP and engine speed.

### ACCELERATION ENRICHMENT

During acceleration the mixture becomes richer based on engine speed, coolant temperature, TPS and MAP and difference in TPS and MAP readings in a given time.

## 4.7 FUEL CUTOFF MODES

There will be no fuel supplied when

- ignition is turned off
- RPM is greater than ~~7719 (N/A)~~ 6.400  
~~7188 (T/C)~~
- RPM is greater than ~~4000~~ 3500 and trouble codes stored 42
- Boost pressure is greater than ~~192 kPa~~ 198 kPa

## 4.8 RUN MODES


The run mode has two possible conditions "Open Loop" or "Closed Loop".

### "OPEN LOOP"

When the engine is first started, the system goes into "Open Loop" operation. In "Open Loop," the ECM ignores the signal from the oxygen ( $O_2$ ) sensor, and calculates the air/fuel ratio based on inputs from the coolant temperature and manifold absolute pressure (MAP) sensors.

The system will stay in "Open Loop" until the following conditions are met:

1. The  $O_2$  sensor has varying voltage output, showing that it is hot enough to operate properly. (This depends on temperature.)
2. The coolant temperature sensor is above a specified temperature.  $54^\circ$
3. A specific amount of time has elapsed after starting the engine.






## 4.9 CLOSED LOOP FUEL CONTROL

The specific values for the above conditions are stored in the memory calibration module (Mem-Cal). When these conditions are met, the system goes into "Closed Loop" operation.

In "Closed Loop," the ECM calculates the air/fuel ratio (injector on-time) based on the signal from the O<sub>2</sub> sensor. This controls the air/fuel ratio very close to 14.6:1.


*WILL GO INTO OPEN LOOP*



## 4.99 BATTERY VOLTAGE CORRECTION MODE

When battery voltage is low, the ECM can compensate for the ~~weak spark delivered by the direct ignition (DI) module by:~~

- Increasing the injector pulse width;
- Increasing the idle rpm;
- Increasing ignition dwell time



\* WILL NOT START IF BATTERY CHARGED FULL \* ?

NO JUMP START) NOT ON RUNNING CAR +  
ONLY ON STANDING BATTERY NO BOOST STA

## LOTUS - OMEGA / CARLTON TRAINING

### 5.0 DIRECT IGNITION SYSTEM

The direct ignition (DI) system does not use the conventional distributor and coil. This ignition system consists of 3 separate ignition coils and an ignition module mounted on a base plate.

A crankshaft position sensor, related connecting wires and the electronic spark timing (EST) portion of the ECM make up the remainder of the system.

A distributorless ignition system, such as this one, uses a "waste spark" method of spark distribution. Each cylinder is paired with its opposite number with each pair of plugs being connected to a single, double-ended coil such that a spark occurs simultaneously in the cylinder coming up on the compression stroke and in the cylinder coming up on the exhaust stroke.

The cylinder on the exhaust stroke requires very little of the available energy to fire the spark plug. The remaining energy will be used as required by the cylinder on the compression stroke. The same process is repeated when the cylinders reverse roles.

#### CRANKSHAFT POSITION SENSOR

A magnetic sensor mounted at the front of the engine, and protruding to within 1.5 mm of the torsional balancer, has a voltage pulse induced in it each time a machined slot in the balancer periphery passes the sensor. There are 6 such slots equi-spaced (60° apart) around the torsional balancer, phased such that one slot passes the sensor when pistons 1/6 are at TDC. A seventh slot, positioned at 10° before the next slot, serves to generate a "sync-pulse".

These pulses are received by the ignition module (located with the ignition coils), which by noting the frequency of the pulses is able to determine engine rpm, and by comparing the time interval between individual pulses can recognize the positional "sync" pulse. The ignition module uses this information to control ignition timing during engine cranking, and also sends reference signals to the ECM at the rate of one every 120° of crankshaft rotation (3 per engine revolution).

These signals inform the ECM of engine speed and position, which it uses to control fuel delivery and, at speeds over 700 rpm, the ignition timing.  
400

#### IGNITION MODULE & H.T. COILS


The ignition module and H.T. coils are mounted as a unit to a chassis bracket at the (RH) side of the engine. Each coil, provides the spark for two plugs simultaneously. LH

The ignition module monitors the crankshaft position sensor signals and sends reference signals to the ECM so that correct spark and fuel injector control can be maintained during all driving conditions. During cranking, the ignition module monitors the "sync-pulse" to begin the ignition firing sequence and below 700 rpm the module controls spark advance by triggering each of the three coils at a pre-determined interval based on engine speed only.  
400


Above 700 rpm the ECM controls the spark timing (EST) and compensates for all driving conditions. The ignition module must receive a "sync-pulse" and then another pulse in that order to enable the ignition coils to be properly sequenced.


CRANKSHAFT  
TORSIONAL  
BALANCER


CRANKSHAFT POSITION SENSOR  
INTERRUPTOR SLOTS (7), NOT TEETH



MS FINANC TO CHECK IF DIRECT ON  
CRANK SHAFT ? NOT UP








**DIRECT  
IGNITION  
SYSTEM  
(DIS)**

IGNITION  
MODULE


- and

# LOTUS - OMEGA / CARLTON TRAINING




## DIRECT IGNITION SYSTEM

*3 pulses / C.R.*







# LOTUS - OMEGA / CARLTON TRAINING




12 +  
✓






## NOTCH EFFECT ON OUTPUT SIGNAL




# LOTUS - OMEGA / CARLTON TRAINING

## DIRECT IGNITION SYSTEM CIRCUITS




# IGNITION MODULE ANALOG - to - DIGITAL SIGNAL CONVERTER OPERATION

1




ONE WAVEFORM SUPERIMPOSED ONTO THE OTHER



# IGNITION MODULE DISCONNECTED FROM ECM

Spark, but no fuel injection pulses

2




# IGNITION MODULE CONNECTED TO ECM

Module (or bypass) mode

Normal while cranking to start.


3



# IGNITION MODULE CONNECTED TO ECM - EST mode

Normal while running.



4



# IGNITION MODULE CONNECTED TO ECM - EST mode

Shown with ECM inputs that affect spark advance

5



**BYPASS** circuit can be either LO, -OR- HI. Voltage originates from ECM.  
 EST mode  $\geq 2.6$  volt. Typical EST mode  $\sim 4.5$ v

EST circuit has a square-wave pulse string, originating from the ECM.  
 In EST mode, pulses are between 0.2 and 5.0 volts. Measuring with a digital DC voltmeter, the voltage will vary with engine RPM


REFERENCE circuit has a square-wave pulse string, originating from the MODULE.  
 Pulses are between 0.2 and 5.0 volts. Measuring with a digital DC voltmeter, the voltage will vary with engine RPM

REFERENCE LOW provides a reference ground point for the reference pulse counter inside the ECM.  
 This circuit is connected to ground ONLY THROUGH THE MODULE!



# IGNITION MODULE CONNECTED TO ECM BYPASS CONTROL


6



# IGNITION MODULE CO. CONNECTED TO ECM - CODE 42 DEFINED, step ① shown

Shown here in **MODULE** mode, with bypass mode control in a **LO** state.

7



**CODE 42** check is performed while cranking to start the engine.

**STEP ①** When bypass control is **LO**, **EST** pulses should be **LO**. This is checked when **RPM** is  $\leq KRPMUP$

**STEP ②** When bypass control is **HI**, **EST** pulses should be **HI**. This is checked when **RPM** is  $\geq KRPMUP$


An open or short to ground in either the **BYPASS** circuit or the **EST** circuit will cause step ① or step ② to be false, and a **CODE 42** will set.

# IGNITION MODULE CONNECTED TO ECM

MODE 42 DEFINED, step ③ shown

Shown here in EST mode, with bypass mode control in a HI state.

8



CODE 42 check is performed while cranking to start the engine.

**STEP ①** When bypass control is L.O., EST pulses should be L.O. This is checked when RPM is  $\leq$  KRPMUP

**STEP ②** When bypass control is HI, EST pulses should be HI. This is checked when RPM is  $\geq$  KRPMUP

An open or short to ground in either the BYPASS circuit or the EST circuit will cause step ① or step ② to be false, and a CODE 42 will set.

# LOTUS - OMEGA / CARLTON TRAINING

## 5.1 ELECTRONIC SPARK TIMING MODES

### BYPASS MODE

The bypass mode allows the DIS to operate independently of the ECM when the ECM is incapable of providing the spark timing information such as at low speeds like cranking, low system voltage, and with certain ECM or system malfunctions.

In the bypass mode, two conditions of operation occur. ~~As shown~~ in the Break Amp (BA) curves, at cranking speeds (defined as below four hundred RPM) where system voltages are expected to be low, the coil current will start at sixty degrees BTDC and stop at TDC. Ignition occurs at the time that the coil break amps stop. This means that at speeds below four hundred RPM, the spark will occur at TDC. As the engine starts and the RPM's increase above four hundred, two changes in operation happen.

1. The point at which ignition occurs will be earlier which will advance the spark timing. The amount of advance is a function of speed and is built into the ignition module. ~~A typical advance for the DIS system is shown in Figure 7.~~

The start of current flow will be delayed so that the time from start of current to ignition will be just sufficient to allow the coil current to rise to the desired break amps. The circuitry constantly monitors this current and adjusts on-time or dwell thus closed loop dwell control. This feature results in less average current and less power dissipation in the system.

### EST MODE

The EST mode of operation occurs after system voltage is up, engine speed is satisfactory and the ECM is computing. At this time the bypass input to the module is raised by the ECM to approximately five volts, and an EST signal is fed into the module. With DIS the fall of current will occur, causing ignition, at the fall of the EST signal, but the start of current will be controlled by the closed loop dwell control and is independent of the rise of the EST signal. The DIS will still select the proper coil to fire.


# LOTUS - OMEGA / CARLTON TRAINING

## 7.0 ELECTRONIC CONTROL MODULE (ECM)

The Electronic Control Module (ECM), ~~located on the right hand fuel tank board~~, is the controlling computer for the fuel injection and engine management system. It constantly monitors data received from various sensors and controls engine operation (fuel management, spark timing and idle speed) to provide optimum performance and driveability consistent with the minimum of harmful emissions.


For service, the ECM consists of only two parts:

- Controller. This is the main body of the ECM and includes the basic control circuits.
- Mem-Cal. This is a "Memory and Calibration" cartridge which plugs into the controller. It is specific to the particular model year of the vehicle, and contains the functions of the PROM - programmable read only memory, Cal Pak - calibration package designed to allow fuel delivery in the event of malfunction in the controller or PROM, as a "get you home" facility, and ESC electronic spark control module.




LOUIS - OMEGA / CARLTON TRAINING

**ECM  
LOCATION**



# LOTUS - OMEGA / CARLTON TRAINING

## 7.1 ECM CONNECTORS



## 8.0 DEFAULT & DIAGNOSTIC MODES

- The system has SELFDIAGNOSTIC capability. In case of a problem it alerts the driver via the "Check Engine Light".
- In case of an input sensor circuit problem the ECM automatically refers to pre-programmed "DEFAULT" values.
- The problem will be stored in ECM memory as a "TROUBLE CODE".
- A technician can read the code when the ECM "DIAGNOSTIC MODE" is requested or when a hand held "Tech 1" scanner tool is connected.
- The ECM also transmits sensor readings and other system parameters to the Tech 1 when "DATA MODE" is requested; this will aid rapid fault diagnosis.
- With the Tech 1 the ECM can be commanded to turn "ON/OFF" relays or solenoids in various "OUTPUT" checking modes.

A.S.

~~XXXXXXXXXX~~



# LOTUS - OMEGA / CARLTON TRAINING

## 8.2 TROUBLE CODES

### OMEGA/CARLTON

THIS IS A SUMMARY OF POSSIBLE TROUBLE CODES ON THE OMEGA/CARLTON. THE "CHECK ENGINE LIGHT" IS SWITCHED "ON" AND A CODE STORED WHEN THE ECM DETECTS ANY OF THE PROBLEMS LISTED BELOW. FOR MORE INFORMATION AND DIAGNOSTIC PROCEDURES REFER TO THE FOLLOWING CHARTS.

CODE	COMPONENT / CIRCUIT	INDICATION
13	Front Oxygen Sensor	Sensor or circuit is open
14	Coolant Temp Sensor	High temperature indicated
15	Coolant Temp Sensor	Low temperature indicated
16	Wastegate	Overboost
21	Throttle Position Sensor	Signal voltage to ECM high
22	Throttle Position Sensor	Signal voltage to ECM low
23	Manifold Air Temp. Sensor	Low temperature indicated
24	Vehicle Speed Sensor	Incorrect signal to ECM
25	Manifold Air Temp. Sensor	High temperature indicated
31	Camshaft speed	Speed NOK
33	Manifold Absolute Pressure	Signal voltage high
34	Manifold Absolute Pressure	Signal voltage low
41	Cylinder select	PROM defect
42	Electronic Spark Timing	EST line fail/ BY PASS ALSO
43	Electronic Spark Control	Detonation circuit failure
44	Front Oxygen Sensor	Lean exhaust indicated
45	Front Oxygen Sensor	Rich exhaust indicated
51	MEM - CAL Error	ECM / MEM-CAL fault
53	Battery Voltage High	Above 17.1 volts at ECM
63	Rear Oxygen Sensor	Sensor or circuit is open
64	Rear Oxygen Sensor	Lean exhaust indicated
65	Rear Oxygen Sensor	Rich exhaust indicated

MANIFOLD

66 TURBO BOOST CONTROL OUTSIDE LIMITS

Summary Lotus Omega/Carlton Trouble Codes

Notes on Use of F0: DATA LIST

- o Should the nominal values not be attained during a test according to the quick check list, trouble-shooting with F0:DATA LIST must be carried out.

In doing this proceed (see example on the following page - test step 06):

- o Commence in the column "Trouble-shooting" upper left. This is operating instruction
- o The control unit will recognise the manipulations carried out in  and the TECH 1 will display the nominal value  but only if the causes of the trouble listed in  are not present.
- o If nominal value  is attained, carry out operating instruction .
- o If nominal value  is also attained, the temperature sensor is defective in the example given below, otherwise check which of the causes of trouble listed under  applies.

# LOTUS - OMEGA / CARLTON TRAINING

## F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
07	COOLANT TEMP.	Engine at idle, operating temp.	> 85° (185°F)	14, 15


### Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

- o Ignition OFF

Remove CTS-plug read temperature on TECH 1 Ignition ON



- o Short circuit between CTS-plug "A" and "B" or
- o Short circuit between CTS-plug "B" and GND.

- o Ignition OFF read temperature on TECH 1 Ignition ON

- o cable interruption between ECM "J2-B9" and CTS-plug Ter. "A"(YN).
- o cable interruption between ECM "J2-B16" and CTS-plug Ter. "B"(BN).
- o loose connection in cable plug or ECM-plug.

- o Check resistance in CT-Sensor between Ter. "A" and "B"

Temperature °C/°F Resistance kΩ


100	/	212	0.185
70	/	158	0.45
38	/	100	1.80
20	/	68	3.40
-	/	4	7.5
-	/	7	25.0
-	/	19	100.7
-	/	0	

# CHECKING PROCEDURES

LOTUS OMEGA/CARLTON

CHECKING WITH TECH 1

PROGRAM-MODUL LOTUS OMEGA/CARLTON 90 ECU



0 2966

SERVICE  
PRODUCT INFORMATION

<b>Table of contents</b>		<b>Page</b>
1	Introduction	4
1.1	The Opel Checking system	4
1.2	General Instructions/Safety Precautions	5
2	Block Diagram of Control Unit	6
3	MODE - DESCRIPTION (CHECKING WITH TECH 1)	7
3.1	Mode F0: Data List	7
3.2	Mode F1: Print Data	7
3.3	Mode F2: Trouble Code	7
3.4	Mode F3: Snapshot	7
3.5	Mode F4: Clear Codes	8
3.6	Mode F5: Actuator Test	8
3.6.1	Submode F0: Fan Relay	8
3.6.2	Submode F1: A/C Relay	8
3.6.3	Submode F2: CCP Valve	8
3.6.4	Submode F3: Waste Gate	8
3.6.5	Submode F4: IAC Motor	8
3.7	Mode F6: ECM Control	9
3.7.1	Submode F0: RPM Control	9
3.7.2	Submode F1: IAC Control	9
3.8	Mode F7: ECM Reset	9
3.8.1	Submode F0: IAC Motor	9
3.8.2	Submode F1: 02 BLM Cells	9
4	Checking	10
4.1	Connecting TECH 1 to Vehicle	10
4.2	Trouble Shooting Chart	11
4.3	Quick Check F0: Data List	13
4.4	F0: Data List	18
4.5	Table 1, Diagnostic Plug ALDL and Voltage Supply, Check	77
4.6	Table 2, Trouble Code Table	80
4.7	Table 3, Part Numbers	88
4.8	Table 4, Instructions for "Engine Does Not Start, Data Transfer OK"	89
4.9	Table 5, F5: Actuator Test	90
4.10	Table 7, F7: ECM Reset	93
5	Terminal Assignment	95
5.1	Terminal Assignment in Diagnostic Plug X 130	95
5.2	Terminal Assignment Oxygen Sensor Plug	96
5.3	Terminal Assignment DI-Module	97
5.4	Terminal Assignment ECM "J1"	98
5.5	Terminal Assignment ECM "J2"	99
5.6	Terminal Assignment ECM "J3"	100
5.7	Terminal Assignment ECM "J4"	101
6	Circuit Diagram	102
6.1	Circuit Diagram LOTUS Omega/Carlton	102

# 1 Introduction

This brochure describes in detail the checking of the LOTUS Omega/Carlton fuel injection system with TECH 1 and the newly developed Program Module "LOTUS Omega/Carlton ECU". These Checking Procedures can also be used to carry out non-electronic trouble-shooting and to read off blink codes.

## 1.1 The OPEL/VAUXHALL Checking System

The "OPEL/VAUXHALL Checking System", a technical testing concept developed by Opel/Vauxhall, has pointed the way for the checking of electronic systems in vehicles.

At the heart of this system are the TECH 1 and TECH 80. With the checking cables and the Electronic Kit I, all Opel vehicles, including those of the new generation, can be checked using the most modern electronic methods.

With the TECH 1 it is possible to read out streams of data from electronic control units. A precondition for this is the use of electronic systems with

- Microprocessor techniques
- Self-diagnosis
- Serial data lines

Before starting the diagnosis the program module appropriate to the model year of the vehicle is plugged in and TECH 1 connected to the diagnostic plug in the vehicle. The streams of data captured on TECH 1 are presented on a 4-line, 16-character display.

The current actual values displayed are compared with the nominal values from the data list. Where there are deviations from the relevant nominal values, a trouble-shooting program is available, so that the user can make a clear diagnosis. The TECH 1 checking concept means rapid and accurate trouble-shooting.

With a special mode called the snapshot mode, misfiring during a test drive caused by loose contacts can be localised - see also TECH 1 Operating Instructions.

## 1.2 General Instructions/Safety Precautions

Readout of date using TECH 1 takes place with IGNITIONS ON and/or with engine operating.

To erase trouble code:


With TECH 1: press key F4

Without TECH 1: switch ignition OFF and disconnect ground from battery for at least 1 minute.  
This also deletes trouble codes, pattern recognition memories etc. of other electronic systems later installed.

Safety Precautions:

- During welding work control units must be removed.
- At temperatures above +80°C/+176°F (drying oven), control units must be removed.
- Never connect or disconnect wiring harness plugs of control units or trigger boxes with ignition switched on.
- Before charging or quick-charging, disconnect the battery from the vehicle electrical system.
- Never use the quick-charger for starting.
- Caution when touching voltage-bearing parts of the ignition system!

**Attention:** After reconnecting the battery it may be necessary to reprogram the electronic window-system and the Anti-Theft-System in the Radio





**3 MODE - Description (Checking with TECH 1)**

The Mode description dealt with in this paragraph refers only to checking with TECH 1. A complete description is to found in the TECH 1 Operator's Manual.

**3.1 MODE F0: DATA LIST**

The actual conditions of all sensors and signals important for proper functioning of the equipment can be called up via the F0 DATA LIST. The actual values shown must then be checked against the nominal values listed in the Checking Procedure. In this way a clear fault diagnosis can be made.

**3.2 MODE F1: NOT USED**

**3.3 MODE F2: TROUBLE CODE**

The F2 mode gives a display of trouble code numbers that have been stored.

**3.4 MODE F3: SNAPSHOT**

The snapshot mode can identify sporadically occurring faults (loose connectors) in the course of a test drive. Extensive description is in the TRCH 1 Operators Manual.

**3.5 MODE F4: CLEAR CODES**

By operating key F4 the trouble codes stored in the ECM can be deleted.

**3.6 MODE F5: ACTUATOR TEST**

By pressing the key F5 the submodes F0 to F4 are available. In all F5-submodes below the engine should be "OFF" and Ignition "ON".

**3.6.1 SUBMODE F0: FAN RELAY**

In submode F0 the FAN RELAY can be activated and checked with the help of TECH 1.

**3.6.2 SUBMODE F1: A/C RELAY**

In submode F1 the A/C RELAY can be activated and checked with the help of TECH 1.

**3.6.3 SUBMODE F2: CCP VALVE**

In submode F2 the CHARCOAL CANISTER PURGE SOLENOID can be activated and checked with the help of TECH 1.

**3.6.4 SUBMODE F3: WASTE GATE**

In submode F3 the WASTE GATE SOLENOID can be activated and checked with the help of TECH 1.

**3.6.5 SUBMODE F4: IAC MOTOR**

In submode F4 the IDLE AIR CONTROL VALVE can be activated and checked with help of TECH 1.

**3.7 MODE F6: ECM CONTROL**

By pressing the key F6 the submodes F0 and F1 are available. In both F6-submodes below the engine is "ON" at idle state.

**3.7.1 SUBMODE F0: RPM CONTROL**

In submode F0 the engine idle speed can be adjusted by using the DESIRED RPM option. The ECM will adjust the IAC until the engine speed is the same as the desired RPM.

**3.7.2 SUBMODE F1: IAC CONTROL**

In submode F1 the IDLE AIR CONTROL VALVE can be adjusted. The ECM will adjust the commanded IAC steps to the desired value. The idle RPM will follow.

**3.8 MODE F7: ECM RESET**

By pressing the key F7 the submodes F0 and F1 are available. In both F7-submodes below the engine is "ON" at idle state.

**3.8.1 SUBMODE F0: IAC MOTOR**

In submode F0 the ECM will make an IDLE AIR CONTROLLER VALVE reset, to find the correct position.

**3.8.2 SUBMODE F1: O2 BIM CELLS**

In submode F1 the O2 BLOCK LEARN MEMORY CELLS will be reset to 128.

#### 4 Checking

##### 4.1 Connecting TECH 1 to Vehicle



Before connecting the instrument one should observe the instructions contained in the TECH 1 Operating Instructions.

- o Ignition OFF
- o Connect TECH 1 to the right AIDL-connector X 130.

Language menu appears in display.

- o Answer LOTUS OMEGA 90-91 ECM with "YES"
- o Answer DISPLAY CAPTURED DATA FROM LAST SNAPSHOT with "NO"
- o Type in Model Year - key 0 - Model Year 1990  
or key 1 - Model Year 1991

- o Answer SELECT BY YES with "YES"
- o Answer COMPARE PROM/MEMCAL ID CODE with "YES" if correct.
- o See chart 3. The ECM now sends data to TECH 1.  
Should there be one or more faults stored in the ECM these will be shown in the display.
- o Note trouble codes.
- o Select F0: DATA LIST with "YES" key.
- o Start engine, idling engine at normal operation temperature.
- o Compare all data shown in display from test step 01 to 39 with following nominal data - section 4.3 and 4.4
- o Actuate "EXIT" key and select F5: ACTUATOR TEST  
Carry out tests.
- o With deviations from the prescribed data, carry out trouble-shooting according to instructions - section 4.4





4.2 Trouble Shooting Chart  
 Should these complaints takes place, the test steps marked with a X should be examined more closely.

Customer Complaint

Customer Complaint	Possible Causes	Test Step No.	Trouble Codes
Leaks/blockages (air or fuel)			
Starter turns, engine starts poorly or not all			
Engine starts but stalls again			
Idling problems (engine speed, exhaust)			
Poor acceptance of fuel, transitional trouble			
Engine misfiring (ignition, injection)			
Fuel consumption too high			
Engine diesels			
Engine pings, knocks			
Engine get too hot			
WOR problem (no top speed)			
Warning lamp permanently or occasionally on			
	Possible Causes	Test Step No.	Trouble Codes
X	FRONT 02 SENSOR, REAR 02 SENSOR, 02 SENSOR LOOP	19, 20, 22,	14, 15
	FRONT 02 SENSOR, FRONT 02 INT., REAR 02 SENSOR	23, 24, 25,	33, 34
	REAR 02 INT., 02 BLM ENABLE, 02 BLM CELL NO.	26, 27, 28,	21, 22
	FONT 02 BLM, REAR 02 BLM	29, 30	
X	MAP SENSOR	31	14, 15
	PAN STATUS	32	33, 34
	A/C REQUEST SW., A/C CLUTCH	33, 34	21, 22
	AUX. WATER PUMP	35	35
X	VEHICLE SPEED	36	35
	IGNITION STATUS	37	13, 44, 45
X	CAMSHAFT SIGNAL	38	13, 44, 45

4.3 Quick Check F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
01	BATTERY VOLTAGE	Ignition ON Start engine Engine at idle speed	11.5 to 13.5V >8V 13.0 to 15.9V	53
02	FUEL PUMP RELAY	Ignition OFF Ignition ON After 3 seconds Start engine, Engine at idle speed	0 to 0.2V 11.5 to 13.5V 0 to 0.2V 13.0 to 15.9V	
03	ENGINE SPEED	Engine at idle, operating temp. AC-switch OFF.	700 to 800 RPM	
04	DESIRED IDLE	Desired Idle * Note: Select TECH 1 -- Mode F6: ECM CONTROL and Submode F0: RPM CONTROL.	750 RPM	
05	TPS SIGNAL	Accelerator in idle position Accelerator in WOT position	0% 0.12 to 0.28 4.8 to 5.0V	21, 22
06	IDLE AIR CONTROL <i>PushStalling 470 Schritte Reset 255 Neuhaltbarwert</i>	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	3 to 12 STEPS	
07	COOLANT TEMP.	Engine at idle, operating temp.	> 85° (185°F) 2.25V	14, 15
08	MAT SENSOR	Engine OFF, engine cold Manifold air between 10°... 30°C 50°... 86°F Start engine, after 5 seconds Engine OFF	37°C DEGrennen der Antriebsmat. CTS - MAT	14, 15, 23, 25

\* 750 RPM is only the desired idle value for engines at operating temperature, that means > 85°C(185°F)

4.3 Quick Check F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
09	MAP SENSOR	Ignition ON $\approx$ 0% - 0.18V Start engine Engine at idle speed 0	0.9-1.1 bar, 2.1-2.65 V 0.25-0.4 bar, 0.62-1 V	33, 34
10	BAROMETER SENSOR <i>170 Amstelheim's DAC</i>	Ignition ON 0.96 bar - 4.55V Start engine Engine at idle speed	0.9-1.1 bar, 4.16-5.0 V 0.9-1.1 bar, 4.16-5.0 V	
11	<del>MAP AIR</del> SPARK ADVANCE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	10 °CA BTDC <i>crankshaft advances ahead angle</i>	
12	KNOCK SIGNAL E	Ignition ON Start engine Engine at idle speed Knock with hammer on engine block*	NOT RECEIVED RECEIVED	16, 66
13	KNOCK RETARD	Ignition ON Start engine Engine at idle speed Knock with hammer on engine block*	0 °CA BTDC 01 to 03 °CA BTDC	16, 66
14	FRONT INJ. PULSE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	2.3 to 3.0 ms	
15	REAR INJ. PULSE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	2.3 to 3.0 ms	
16	WASTE GATE FUNCT	Engine at idle, operating temp.	ENABLED	16, 66

\* Near Knock Sensor . Use a one pound (400..600 g) hammer. If no reaction : drive car on road.



4.3 Quick Check F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
17	WASTE GATE D.C.	Engine at idle, operating temp.	100 % or 0 % but not between !!	16, 66
18	WASTE GATE BLM	Engine at idle, operating temp.	-5 % .. +5 %	16, 66
19	FRONT O2 SENSOR	Engine at idle, operating temp. AC-switch OFF.	READY	13, 44, 45
20	REAR O2 SENSOR	Engine at idle, operating temp. AC-switch OFF.	READY	63, 64, 65
21	TIME FROM START	Ignition ON Start engine Engine at idle speed	00:00:00 ✓ > 00:00:00 ✓	
22	O2 SENSOR LOOP	Ignition ON Start engine Engine at idle speed	OPEN ✓ CLOSED ✓	
23	FRONT O2 SENSOR	Ignition ON Start engine Engine at idle speed	440 to 460 mV ✓ 50 to 950 mV ✓	13, 44, 45
24	FRONT O2 INT.	Ignition ON <i>max 10 minutes</i> Start engine Engine at idle speed	128 STEPS ✓ <i>CF?</i> <i>123 Schritte</i> 123 to 133 STEPS ✓	13, 44, 45

*Max 10 min. Start*

4.3 Quick Check FO: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
25	REAR O2 SENSOR	Ignition ON Start engine Engine at idle speed	440 to 460 mV ✓ 50 to 950 mV ✓	63, 64, 65
26	REAR O2 INT.	Ignition ON Start engine Engine at idle speed	128 STEPS ✓ 123 to 133 STEPS ✓	63, 64, 65
27	O2 BLM ENABLE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	ACTIVE ✓	13, 44, 45, 63, 64, 65
27A	<del>O2 BLM ENABLE</del>			
28	O2 BLM CELL NO.	Ignition ON, Start engine Engine at idle speed Engine speed > 2000 RPM and MAP-Sensor > 0.65 bar	0 ✓ > 0 <i>CELL NO</i>	<i>BLIP THROTTLE, QU...</i>
29	FRONT O2 BLM	Ignition ON Start engine Engine at idle speed	128 STEPS ✓ 110 to 145 STEPS.	63, 64, 65
30	<del>O2 BLM</del> REAR O2 BLM	Ignition ON Start engine Engine at idle speed	128 STEPS 110 to 145 STEPS ✓	63, 64, 65
30A	<del>O2 BLM</del>			
31	<del>CANISTER PURGE</del>	Ignition ON Start engine Engine at idle speed Engine speed out of idle, TPS > 4%	0% > 1% ?	
32	FAN STATUS	Ignition ON Start engine, Engine at idle speed Coolant temperature > 97°C, 207°F	OFF 12V ✓ ON 0V ✓	
32A	<del>FAN STATUS</del>			

4.3 Quick Check F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
33	A/C REQUEST	Engine at idle speed AC-switch OFF AC-switch ON	OFF 12V 0V ON 0V 12V	
34	A/C CHUTCH <i>Cur off Delay</i>	Engine at idle speed AC-switch OFF AC-switch ON , after 1 second	<i>Disengage</i> OFF 12V ON 0V	
35	AUX. WATER PUMP	Ignition ON Start engine, Engine at idle speed Coolant temperature > 93°C, 200°F Engine OFF, Ignition OFF	OFF 12V ✓ ON 0V ✓	
36	VEHICLE SPEED	Compare speedometer reading with TECH 1 value	Aprox. same speed <i>12 km.</i>	24
37	IGNITION STATUS	Ignition ON Start engine Engine at idle speed	BYPASS ✓ BST ✓	
38	CRANKSHAFT SIGNAL	Ignition ON Start engine Engine at idle speed	VALID ✓	
39	CONTROLLED IAC	Desired IAC step value Note: Select TECH 1 <i>EXIF</i> MODE F6: ECM CONTROL and SUBMODE F1: IAC CONTROL.	<i>96</i> STEPS ✓ <i>max 96</i> <i>Normal</i>	

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
01	BATTERY VOLTAGE	Ignition ON Start engine Engine at idle speed	11,5 to 13,5V ✓ >8V ✓ 13,0 to 15,9V ✓	53
<b>Trouble-shooting:</b>				
<b>Measure battery voltage using Multimeter</b>				
<b>Nominal Values:</b>				
<b>Cause of Fault:</b> (If nominal values NOT attained)				
o Engine OPF		> 11.5 V	o Battery flat	
o Start engine		> 8.0 V	o Battery flat	
o Engine running		>13.0 V	o Check alternator or regulator	
o Voltage acc. to TRCH 1		13 to 17.1 V	o If alternator and regulator OK, ECM defective.	
<p>If ECM detects a battery voltage greater than 17.1 V without setting a CODE 53 change ECM.</p>				

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
02	FUEL PUMP RELAY	Ignition OFF Ignition ON After 3 seconds Start engine, Engine at idle speed	0 to 0,2V 11,5 to 13,5V 0 to 0,2V ?- 13,0 to 15,9V	
<p>Trouble-shooting:</p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Measure relay voltage between relay terminal-color "P" and ground. Using Multimeter. (20V/DC)</p> <p style="text-align: right;">&gt; 11 V</p> <p>o Fuse "FUEL PUMP RELAY", "MAXIFUSE" blown</p> <p>o CKT open between Fuse "FUEL PUMP RELAY" and "MAXIFUSE" or CKT open between Fuse-"FIA" "FUEL PUMP RELAY" and relay Ter. (color "P").</p>				
<p>o Disconnect fuel pump relay. Short fuel pump relay Ter.(color "P" and "OW")</p> <p style="text-align: right;">&gt; 11 V Fuse OK</p> <p>o Short to ground in CKT from FUEL PUMP RELAY Ter.(color "OW") to FUEL PUMP Ter.(color "OW") or FUEL PUMP defective.</p>				
<p>o Measure resistance between relay Ter. (color "N") and ground. Using Multimeter (200 Ω). Ignition OFF</p> <p style="text-align: right;">&lt; 1 Ω</p> <p>o CKT open.</p>				
<p>o Measure voltage on ECM "J1-A19" to ground. Using Multimeter. (20V/DC) Ignition OFF, Ignition ON</p> <p style="text-align: right;">&gt; 11 V 3 seconds later &lt; 1 V</p> <p>o ECM defective or grounded CKT between Fuel pump relay "Op" and ECM "J1-A19"</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
02 Part - 2	FUEL PUMP RELAY	Ignition OFF Ignition ON After 3 seconds Start engine, Engine at idle speed	0 to 0,2V 11,5 to 13,5V 0 to 0,2V 13,0 to 15,9V	
<p><b>Trouble-shooting:</b></p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o Measure relay voltage between relay terminal-color "Op" and ground. Using Multimeter. (20V/DC) Reconnect fuel pump relay. Ignition OFF, Ignition ON</p> <p>&gt; 11 V, relay ON 3 seconds later &lt; 1 V, relay OFF</p> <p>o Open CKT between Fuel pump relay "Op" and ECM "J1-A19" or Fuel pump relay defective.</p>				
<p>o Measure relay voltage between relay terminal-color "OW" and ground. Using Multimeter. (20V/DC) Ignition OFF, Ignition ON</p> <p>&gt; 11 V, relay ON Fuel pump ON 3 seconds later &lt; 1 V, relay OFF Fuel pump OFF</p> <p>o Open circuit between relay and fuel pump or Fuel pump defective.</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
03	ENGINE SPEED	Engine at idle, operating temp. AC-switch OFF.	700 to 800 RPM	

Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

o Engine starts


OK

o See Table 4

o Engine running at idle

700 to 800 RPM


o Compare wave form



Multimeter Voltage (20V/AC) ~ 2.4 - 2.6 V

o Engine running at idle  
or use Multimeter

wave form OK  
See Voltage  
above



Signal not OK

o Short or open CKT between  
"J4-D13" and DIS-Module "F"  
"J4-D18" and DIS-Module "E"

or o See next page

or

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
03 Part - 2	ENGINE SPEED	Engine at Idle, operating temp. AC-switch OFF.	700 to 800 RPM	


Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)


o Engine running at idle 700 to 800 RPM

o See wave form: DIS-Module, crank signal input between terminal "A" and "C"



Multimeter Voltage (20V/AC) ~ 1.8 - 2.2 V

Signal not OK



o Engine running at idle or use Multimeter

wave form OK  
See voltage above

- o Short or open CKT between Crank sensor and DIS-Module "A" or Crank sensor and DIS-Module "C".
- o Crank sensor defective.
- o Segment disc/teeth corroded.
- o Metal shavings on pulse pick-up.



4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
03 Part - 3	ENGINE SPEED	Engine at idle, operating temp. AC-switch OFF.	700 to 800 RPM	

Trouble-shooting:


Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

- o Engine running at idle
- o Engine running at idle

CAM signal OK  
No Code 31

- o See wave form: CAM-signal on Ter. "J4-D3"



Multimeter Voltage (20V/AC) ~ 1.35 - 1.55 V

- o Engine running at idle
- o Engine running at idle
- o Engine running at idle
- o Check spark plugs

700 to 800 RPM

- o See test step 5, 6, 7, 8, 9, 10, 13, 32, 33, 34 and 36

all above named test steps OK

- o Repair system.

spark plugs OK

- o Change defective spark plug.

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
04	DESIRED IDLE	Desired Idle Notes: Select TECH 1 Mode F6: ECM CONTROL and Submode F0: RPM CONTROL.	750 RPM	

Trouble-shooting: Nominal Value: Cause of Fault:  
(If nominal values NOT attained)

o The test step DESIRED IDLE is only in TECH 1 Mode F6:ECM CONTROL part F0:RPM CONTROL available.  
This test step can be used to examine the conduct of the engine, when the engine speed is greater or less than idle.

. In this test step, the ECM instructs the IAC stepper motor to increase or decrease the step value until the desired engine speed is reached.

o Select Mode F6:ECM CONTROL TECH 1 display: o ECM defective  
Submode F0:RPM CONTROL YYY RPM . see test step 06  
engine speed YYY RPM\*

o Press arrow key 'up' speed increases up to 1600 RPM o ECM defective  
see test step 06

Press arrow key 'down' speed decreases down to 600 RPM

Note: The TECH 1 SNAPSHOT Mode is enabled.

\* If the Submode F0:RPM CONTROL is enabled by using the "YES" key, the displayed idle speed will be equal to the actual idle speed.

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
05	TPS SIGNAL	Accelerator in idle position Accelerator in WOT position	0.12 to 0.28V 4.8 to 5.0V	21, 22
<p><b>Trouble-shooting:</b></p> <p style="text-align: center;">Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Ignition OFF Remove MAP-sensor plug Remove Baro-sensor plug Ignition ON Accelerator in idle position --&gt; 0.12 to 0.28V Accelerator in WOT position --&gt; 4.8 to 5.0V</p> <p style="text-align: right;">o See next page</p>				
<p>o Ignition OFF Connect MAP-sensor plug Ignition ON Accelerator in idle position --&gt; 0.12 to 0.28V Accelerator in WOT position --&gt; 4.8 to 5.0V</p> <p style="text-align: right;">o MAP-sensor defective or short or open in CKT to MAP-sensor to ECM See test step 9</p>				
<p>o Ignition OFF Connect Baro-sensor plug Ignition ON Accelerator in idle position --&gt; 0.12 to 0.28V Accelerator in WOT position --&gt; 4.8 to 5.0V</p> <p style="text-align: right;">o Baro-sensor defective or short or open in CKT to Baro-sensor to ECM See test step 10</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
05 Part - 2	TPS SIGNAL	Accelerator in idle position Accelerator in WOT position	0.12 to 0.28V 4.8 to 5.0V	21, 22
Trouble-shooting:				
Nominal Value:				
Cause of Fault: (If nominal values NOT attained)				
o Ignition OFF Remove TP-Sensor Ignition ON		0 V	o Short circuit between cable TPS-plug ter."2"(UK) and TPS-plug ter."3"(S). • BCM defective	
o Ignition OFF Jumper wire between TPS-plug ter."2"(UK) and TPS-plug ter."3"(S).		5 V	o Short circuit between cable TPS-plug ter."2"(UK) and TPS-plug ter."1"(BN). • cable interruption "J2-B5" to TPS-plug ter."3"(S). • cable interruption "J2-B3" to TPS-plug ter."2"(UK). • BCM defective.	
o Check connection between TPS-plug ter."1"(BN) and BCM "J2-B16"		Continuity	o cable interruption	

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
05 Part - 3	TPS SIGNAL	Accelerator in idle position Accelerator in WOT position	0.12 to 0.28V 4.8 to 5.0V	21, 22
<p>Trouble-shooting: <span style="float: right;">Nominal Value:</span></p> <p>o Ignition OFF Measure resistance between Ter. "1" and "3" <span style="float: right;">5 to 6 kΩ</span></p> <p>o Measure resistance between Ter. "1" and "2" Throttle closed <span style="float: right;">500 to 550 Ω</span></p> <p>o Measure resistance between Ter. "1" and "2" Throttle open <span style="float: right;">5.5 to 6.0 kΩ</span></p> <p>o Check TPS-plug for corrosion <span style="float: right;">OK</span></p> <p style="text-align: right;">Cause of Fault: (If nominal values NOT attained)</p> <p>o Throttle valve potentiometer defective</p> <p>o Throttle valve potentiometer defective</p> <p>o Throttle valve potentiometer defective</p> <p>o Repair or replace plug.</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
06	IDLE AIR CONTROL	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	3 . . 12 STEPS	
Trouble-shooting:				
Nominal Value:				
Cause of Fault: (If nominal values NOT attained)				
<ul style="list-style-type: none"> <li>o Disconnect IAC-plug</li> <li>Select TECH 1 mode:</li> <li>P5: ACTUATOR TEST</li> <li>Select Submode:</li> <li>P4: IAC MOTOR</li> <li>Measure voltage between</li> <li>Ter. "A" and "C" (female) and</li> <li>Ter. "B" and "D" (female)</li> <li>(Multimeter 20V/AC)</li> </ul>	<ul style="list-style-type: none"> <li>A/C : ~ 6,6 V</li> <li>B/D : ~ 6.6 V</li> </ul>	<ul style="list-style-type: none"> <li>o Interruption between IAC-valve and ECM</li> <li>IAC: Ter. "A" --&gt; ECM : J1-A4</li> <li>IAC: Ter. "B" --&gt; ECM : J1-A9</li> <li>IAC: Ter. "C" --&gt; ECM : J1-A5</li> <li>IAC: Ter. "D" --&gt; ECM : J1-A10</li> <li>or short to ground.</li> </ul>		
<ul style="list-style-type: none"> <li>o Ignition OFF</li> <li>Remove IAC stepper motor</li> <li>Reconnect IAC-plug.</li> <li>Ignition ON</li> <li>Select TECH 1 mode:</li> <li>P5: ACTUATOR TEST</li> <li>Select Submode:</li> <li>P4: IAC MOTOR</li> </ul>	<ul style="list-style-type: none"> <li>o Pintle moves out</li> <li>an in.</li> </ul>	<ul style="list-style-type: none"> <li>o IAC stepper motor defective.</li> </ul>		

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
06 Part - 2	IDLE AIR CONTROL	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	3 . . 12 STEPS	
<p>Trouble-shooting:</p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Disconnect IAC-plug Check coil resistance between Ter. "A" and "B" and Ter. "C" and "D".</p> <p>20 to 100 Ω</p> <p>o IAC stepper motor defective.</p>				
<p>o Check isolation between Ter. A,B,C and D against IAC-body.</p> <p>∞ Ω</p>				
<p>o Select TRCH 1 Mode: P6: ECM CONTROL Select TRCH 1 Submode: P1: IAC CONTROL Push arrow "UP" to increase engine idle speed to 1500 RPM Push arrow "DOWN" to decrease engine idle speed to 800 RPM</p> <p>----&gt; engine Speed 1500 RPM</p> <p>----&gt; engine Speed 800 RPM</p> <p>o Further reasons see next page.</p> <p>o leakage in manifold system. . Code 21 or 22 detected. . Throttle valve bypass screw out of adjustment. (change basic setting only in emergency. See next page)</p>				

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
06	IDLE AIR CONTROL	Engine at Idle, operating temp. AC-switch OFF. Switch OFF all consumers.	3 . . 12 STRPS	
<p>Part - 3</p> <p>Trouble-shooting:</p> <p style="text-align: center;">Nominal Value:                      Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Further reasons :</p> <p>o Seat of IAC stepper motor is dirty</p> <p>o Odometer frequency sensor or circuit is defective.</p> <p>o Throttle valve not closing</p> <p>o TP - Sensor is defective.</p> <p>o Ignition cable, spark plugs defective</p> <p>o Mixture to rich/lean</p> <p>o Batt. voltage to high/low</p>				
<p>NEW BASIC SETTING of the</p> <p>Throttle valve bypass screws:</p> <p>Test followed test steps first</p> <p>Engine at idle speed all consumers switched off</p> <p>o BATTERY VOLTAGE    o MAP SENSOR                      if OK then ----&gt;</p> <p>TPS SIGNAL                      BAROMETER SENSOR</p> <p>COOLANT TEMP.                      ENGINE SPEED</p> <p>MAP SENSOR                      KNOCK RETARD</p> <p>FRONT 02 INT.                      REAR 02 INT.</p> <p>FRONT 02 BLM                      REAR 02 BLM</p> <p>CANISTER PURGE                      PAN STATUS</p> <p>A/C REQUEST SW.                      A/C CLUTCH</p> <p>IGNITION STATUS                      VEHICLE SPEED</p> <p>all test steps OK                      o reaire system</p> <p>o TPS between 0.12 and 0.28 V</p> <p>o Close front bypass screw. IAC step rate increases.</p> <p>o Close rear bypass screw. IAC step rate increases again.</p> <p>o Open both bypass screws synchron until IAC step rate decreases to 10 steps.</p> <p>o In this case the MAP SENSOR value will be between 0.29 and 0.4 bar</p>				



4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes																
07	COOLANT TEMP.	Engine at Idle, operating temp.	> 85° (185°F)	14, 15																
<p><b>Trouble-shooting:</b></p> <p><b>Nominal Value:</b></p> <p>Cause of Fault: (If nominal values NOT attained)</p> <ul style="list-style-type: none"> <li>o Ignition OFF Remove CTS-plug. read temperature on TECH 1 Ignition ON</li> <li>-39°C / -38°F</li> <li>o Short circuit between CTS-plug "A" and "B"</li> <li>o Short circuit between CTS-plug "B" and GND.</li> <li>o Ignition OFF <sup>Turn over CTS-plug</sup> read temperature on TECH 1 Ignition ON</li> <li>+151°C / +304°F</li> <li>o cable interruption between ECM "J2-B9" and CTS-plug Ter. "A"(YN).</li> <li>o cable interruption between ECM "J2-B16" and CTS-plug Ter. "B"(BN).</li> <li>o loose connection in cable plug or ECM-plug.</li> <li>o Temperature sensor defective</li> </ul> <p>o Check resistance in CT-Sensor between Ter. "A" and "B"</p>																				
<table border="1"> <thead> <tr> <th>Temperature °C/°F</th> <th>Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td>100 / 212</td> <td>0.185</td> </tr> <tr> <td>70 / 158</td> <td>0.45</td> </tr> <tr> <td>38 / 100</td> <td>1.80</td> </tr> <tr> <td>20 / 68</td> <td>3.40</td> </tr> <tr> <td>- 4 / 25</td> <td>7.5</td> </tr> <tr> <td>- 7 / 19</td> <td>25.0</td> </tr> <tr> <td>- 18 / 0</td> <td>100.7</td> </tr> </tbody> </table>					Temperature °C/°F	Resistance kΩ	100 / 212	0.185	70 / 158	0.45	38 / 100	1.80	20 / 68	3.40	- 4 / 25	7.5	- 7 / 19	25.0	- 18 / 0	100.7
Temperature °C/°F	Resistance kΩ																			
100 / 212	0.185																			
70 / 158	0.45																			
38 / 100	1.80																			
20 / 68	3.40																			
- 4 / 25	7.5																			
- 7 / 19	25.0																			
- 18 / 0	100.7																			

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes																
08	MAT SENSOR	Engine OFF, engine could Manifold air between 10°... 30°C 50°... 86°F Start engine, after 5 seconds Engine OFF	CTS ~ MAT	14, 15, 23, 25																
Troubleshooting: <ul style="list-style-type: none"> <li>o Ignition OFF Remove MAT plug. read temperature on TRCH 1 Ignition ON</li> <li>o Ignition OFF <sup>(MAT plug)</sup> read temperature on TRCH 1 Ignition ON</li> </ul>																				
Nominal Value: <ul style="list-style-type: none"> <li>-39°C / -38°F</li> <li>+151°C / +304°F</li> </ul>																				
Cause of Fault: (If nominal values NOT attained) <ul style="list-style-type: none"> <li>o Short circuit between MAT-plug "A" and "B" OR</li> <li>o Short circuit between MAT-plug "B" and GND.</li> <li>o cable interruption between ECM "J2-B21" and MAT-plug Ter. "A"(NK).</li> <li>o cable interruption between ECM "J2-B22" and MAT-plug Ter. "B"(B0).</li> <li>o loose connection in cable plug or ECM-plug.</li> </ul>																				
o Check resistance in MAT-Sensor between Ter. "A" and "B"																				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Temperature °C/°F</th> <th style="width: 50%;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td>100 / 212</td> <td>0.185</td> </tr> <tr> <td>70 / 158</td> <td>0.45</td> </tr> <tr> <td>38 / 100</td> <td>1.80</td> </tr> <tr> <td>20 / 68</td> <td>3.40</td> </tr> <tr> <td>4 / 25</td> <td>7.5</td> </tr> <tr> <td>7 / 19</td> <td>25.0</td> </tr> <tr> <td>18 / 0</td> <td>100.7</td> </tr> </tbody> </table>					Temperature °C/°F	Resistance kΩ	100 / 212	0.185	70 / 158	0.45	38 / 100	1.80	20 / 68	3.40	4 / 25	7.5	7 / 19	25.0	18 / 0	100.7
Temperature °C/°F	Resistance kΩ																			
100 / 212	0.185																			
70 / 158	0.45																			
38 / 100	1.80																			
20 / 68	3.40																			
4 / 25	7.5																			
7 / 19	25.0																			
18 / 0	100.7																			
o MAT-Sensor defective																				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
09	MAP SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 2.1-2.65 V 0.25-0.4 bar, 0.62-1.0 V	33, 34
<p>Trouble-shooting:</p> <p style="text-align: center;">Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Ignition OFF Remove TP-Sensor plug Remove MAT-sensor plug Ignition ON Start engine Engine at Idle speed</p> <p style="text-align: center;">o See next page</p>				
<p>o Ignition OFF Connect MAT-sensor plug Ignition ON Start engine Engine at idle speed</p> <p style="text-align: center;">o MAT-sensor defect or short or open in CKT to MAT-sensor to ECM See test step 08</p>				
<p>o Ignition OFF Connect TP-Sensor plug Ignition ON Start engine Engine at idle speed</p> <p style="text-align: center;">o TP-Sensor defect or short or open in CKT to TP-Sensor to ECM See test step 05</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
09	MAP SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 2.1-2.65 V 0.25-0.4 bar, 0.62- 1 V	33, 34
<b>Trouble-shooting:</b> Nominal Value: (If nominal values NOT attained)				
<ul style="list-style-type: none"> <li>o Ignition OFF Remove MAP-sensor Ignition ON</li> </ul>				
<ul style="list-style-type: none"> <li>o Short circuit between cable MAP-plug ter. "B" (G1G) and MAP-plug ter. "C" (S). ECM defective.</li> </ul>				
<ul style="list-style-type: none"> <li>o Short circuit between cable MAP-plug ter. "B" (G1G) and MAP-plug ter. "A" (B0). cable interruption "J2-B4" to MAP-plug ter. "B" (G1G). cable interruption "J2-B5" to MAP-plug ter. "C" (S). ECM defective.</li> </ul>				
<ul style="list-style-type: none"> <li>o Ignition OFF Jumper wire between MAP-plug ter. "B" (G1G) and MAP-plug ter. "C" (S).</li> </ul>				
<ul style="list-style-type: none"> <li>o Check connection between MAP-plug ter. "A" (B0) and BCM "J2-B22"</li> </ul>				
Continuity, < 1 Ω      o cable interruption				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
09	MAP SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 2.1-2.65 V 0.25-0.4 bar, 0.62- 1 V	33, 34
Part - 3				

Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

Reconnect MAP-Sensor.  
o Connect vacuum pump

o MAP-Sensor defective.

KM-J-23994-8 to

MAP-Sensor. Set vacuum pressure at nominal value and after each change in pressure, switch Ignition OFF and ON again.

Vacuum-value on vacuum tester		Volt-value on TECH 1	
0 kPa,	0 bar (0	1bf/in <sup>2</sup> )	2.3 .. 2.6 VOLT
20 kPa,	0.2 bar (2.9	1bf/in <sup>2</sup> )	1.7 .. 1.9 VOLT
60 kPa,	0.6 bar (8.7	1bf/in <sup>2</sup> )	0.6 .. 0.9 VOLT
80 kPa,	0.8 bar (11.6	1bf/in <sup>2</sup> )	0.1 .. 0.4 VOLT

o Vacuum pressure hose to sensor is leaking or blocked.

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
10	BAROMETER SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 4.16-5.0 V 0.9-1.1 bar, 4.16-5.0 V	
<p>Trouble-shooting:</p> <p style="text-align: center;">Nominal Value:</p>				
<p>o Ignition OFF Remove TP-Sensor plug Remove CT-Sensor plug Ignition ON</p> <p style="text-align: center;">0.9-1.1 bar, 4.16-5.0 V</p> <p style="text-align: right;">Cause of Fault: (If nominal values NOT attained)</p> <p>o See next page</p>				
<p>o Ignition OFF Connect CT-sensor plug Ignition ON</p> <p style="text-align: center;">0.9-1.1 bar, 4.16-5.0 V</p> <p style="text-align: right;">Cause of Fault: (If nominal values NOT attained)</p> <p>o MAT-sensor defect or short or open in CKT to MAT-sensor to ECM . See test step 08</p>				
<p>o Ignition OFF Connect TP-Sensor plug Ignition ON</p> <p style="text-align: center;">0.9-1.1 bar, 4.16-5.0 V</p> <p style="text-align: right;">Cause of Fault: (If nominal values NOT attained)</p> <p>o TPS-sensor defect or short or open in CKT to TPS-sensor to ECM . See test step 05</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
10	BAROMETER SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 4.16-5.0 V 0.9-1.1 bar, 4.16-5.0 V	
Trouble-shooting:				
Nominal Value:				
Cause of Fault: (If nominal values NOT attained)				
o Ignition OFF Remove Baro-sensor Ignition ON		0 V		o Short circuit between cable BPS-plug ter. "B" (IGY) and BPS-plug ter. "C" (S). . ECM defect
o Ignition OFF Jumper wire between BPS-plug ter. "B" (IGY) and BPS-plug ter. "C" (S).		5 V		o Short circuit between cable BPS-plug ter. "B" (IGY) and BPS-plug ter. "A" (BN). . cable interruption "J2-B12" to BPS-plug ter. "B" (IGY). . cable interruption "J2-B5" to BPS-plug ter. "C" (S). . ECM defective
o check connection between BPS-plug ter. "A" (BN). and ECM "J2-B16"		Continuity, < 1 Ω		o cable interruption

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
10	BAROMETER SENSOR	Ignition ON Start engine Engine at idle speed	0.9-1.1 bar, 4.16-5.0 V 0.9-1.1 bar, 4.16-5.0 V	

Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

Reconnect Baro-sensor.

o Connect vacuum pump

KM-J-23994-8 to

Baro-sensor. Set vacuum

pressure at nominal value

and after each change in

pressure, switch ignition OFF

and ON again.

o Baro-sensor defective.

	Vacuum-value on vacuum tester	Volt-value on TECH 1
0 KPa, 0 bar (0 lbf/in <sup>2</sup> )	4.7 .. 5.1 Volt	
20 kPa, 0.2 bar (2.9 lbf/in <sup>2</sup> )	3.5 .. 3.9 Volt	
60 kPa, 0.6 bar (8.7 lbf/in <sup>2</sup> )	1.3 .. 1.7 Volt	
80 kPa, 0.8 bar (11.6 lbf/in <sup>2</sup> )	0.3 .. 0.7 Volt	





4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
12	KNOCK SIGNAL	Ignition ON Start engine Engine at idle speed Knock with hammer on engine block *	NOT RECEIVED  RECEIVED	16, 66
<p>Trouble-shooting:</p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Check connection between Knock sensor plug (U) and ECM "J2-B20" Continuity, &lt; 1 Ω o cable interruption</p> <p>o Check connection between Knock sensor screw and engine block. Continuity, &lt; 1 Ω o clean block cavity and knock sensor.</p>				
<p>o Reconnect knock sensor Ignition ON, Disconnect knock sensor plug. Measure voltage on ECM "J2-B20" to GND 4.5 ... 5.2 V (rang 20V/DC) o replace ECM.</p>				
<p>o Reconnect knock sensor plug Measure voltage on ECM "J2-B20" to ground. 2.1 ... 2.9 V (rang 20V/DC) o replace Sensor</p>				
<p>o Ignition OFF Ignition ON Start engine Engine at idle speed Knock with hammer on engine block NOT RECEIVED o replace ECM.</p> <p>o Ignition ON NOT RECEIVED o replace new spark-plugs. o remove combustion chamber deposits.</p>				
<p>* Near Knock Sensor . Use a one pound (400..600 g) hammer.</p>				

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
13	KNOCK RETARD	Ignition ON Start engine Engine at idle speed Knock with hammer on engine block *	1 to 3 0 CA BTDC CA BTDC	16, 66

Trouble-shooting: Nominal Value: Cause of Fault: (If nominal values NOT attained)

o See test step 12 OK o Repair sensor or CKT.

o Ignition OFF o replace Sensor  
Ignition ON

Engine at idle speed 0 CA BTDC  
Knock with hammer on engine block 1 to 3 CA BTDC

o Ignition OFF o replace ECM  
Ignition ON

Start engine 0 CA BTDC  
Engine at idle speed 1 to 3 CA BTDC  
Knock with hammer on engine block

o Ignition ON o replace new spark-plugs.  
Start engine remove combustion chamber deposits.  
Engine at idle speed 0 CA BTDC

\* Select TECH 1 Mode F6: ECM CONTROL. Use Submode F0:RPM CONTROL and set idle speed to 1600 RPM. Knock near Sensor . Use a one pound (400.600 g) hammer. If no reaction: drive car on road.

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
14	FRONT INJ. PULSE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	2.3 to 3.0 ms	

This test step serves as a learning and checking value to understand the system better and to evaluate the system on external influences.

The injection time is composed of several elements, which have a influence on the pulsewidth of the signal.

The BCM handles the injection time for the cylinders Nr. 1, 2, and 3 ( front engine) independent from the rear engine (cylinders Nr. 4, 5, and 6), so may it be possible, that one part of the engine is running closed loop and the other open loop.

If no fault exists, the TRCH 1 should show the same values for front and rear part of the engine.

The following test steps may have influence of the correct injection time.

Test step No.:	Checking of	Test step No.:	Checking of :
01	BATTERY VOLTAGE	26	REAR 02 INT.
03	FUEL PUMP RELAY	30	REAR 02 BLM
05	TPS SIGNAL	31	CANISTER PURGE
06	IDLE AIR CONTROL	32	FAN STATUS
07	COOLANT TEMP.	33	A/C REQUEST
08	MAP SENSOR	36	VEHICLE SPEED
09	MAP SENSOR		
10	BAROMETRER SENSOR		
11	SPARK ADVANCE		
13	KNOCK RETARD		
17	WASTE GATE D.C.		
18	WASTE GATE BLM		
24	FRONT 02 INT.		
29	FRONT 02 BLM		

o Further additional causes of trouble are:  
 . Pressure regulator defective.  
 . Injectors blocked up.  
 . lead interruptions from fuel pump relay  
 Ter.-color (OW) to Injectors.  
 . Fuel pump pressure/flow less than necessary.

4.4 3000 #2

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
14 Part - 2	FRONT INJ. PULSE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	2.3 to 3.0 ms	
<p>Trouble-shooting:</p> <p style="text-align: center;">Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Compare injection time in test step 14 and test step 15</p> <p style="text-align: center;">test step 14 ~ test step 15 value value</p> <p style="text-align: center;">. see test step 06, 09, 10, 17, 24, 31 and 29(cell No. 0)</p>				
<p>o Select F5: ACTUATOR TEST</p> <p style="text-align: center;">Injectors OK</p> <p>o replace defective valves.</p>				
<p>o Search for leaks in exhaust system.</p> <p style="text-align: center;">no leaks</p> <p>o repair exhaust system.</p>				
<p>o Search for defective CKT in test step 23</p> <p style="text-align: center;">CKT's OK</p> <p>o repair system.</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
15	REAR INJ. PULSE	Engine at idle, operating temp. AC-switch OFF. Switch OFF all consumers.	2.3 to 3.0 ms	

Note: See Text in test step 14 (Part 1)

**Trouble-shooting:**

**Nominal Value:**

**Cause of Fault:**  
(If nominal values NOT attained)

o Compare injection time in test step 14 and test step 15

test step 14 ~ test step 15 value value

o Search for leaks (air and/or fuel) in intake manifold  
 . See test step 06, 09, 10, 17, 25, 31 and 30(cell No. 0)

o Select P5: ACTUATOR TEST

Injectors OK

o Replace defective valves.

o Search for leaks in exhaust system.

no leaks

o Repair exhaust system.

o Search for defective CKT in test step 25

CKT's OK

o Repair system.

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
16	WASTE GATE FUNCT	Engine at idle, operating temp. If DISABLED displayed on TECH 1 a Malfunction is recognized	ENABLED	16, 66

The waste gate actuator contains an internal spring to preload the waste gate closed. Normally boost pressure is controlled by applying intake manifold pressure to a small hose to the waste gate actuator. The actuator is constructed with spring pressure applied to one side of the diaphragm, and the opposite side of the diaphragm exposed to manifold pressure through the connecting hose. At 1.55 bar (8 PSI), manifold pressure would overcome spring pressure, and the diaphragm would begin to move, causing the waste gate to open. If the hose is either blocked or removed from the actuator, or a leak exists in the hose, the waste gate would not open, and engine protection would be achieved only by the overboost protection in the ECM. When the ECM detects a manifold pressure of 1.98 bar the ECM will discontinue all fuel injection pulses until manifold pressure drops below 1.6 bar. Inserted to the hose, between the actuator and the compressor side of the turbocharger, is a normal open, ECM controlled solenoid (WASTE GATE SOLENOID VALVE). The solenoid controls how much manifold pressure is directed to the waste gate actuator.

If the WASTE GATE SOLENOID VALVE or control circuit were to fail in a fully-energized, 100% duty cycle mode, the maximum boost pressure could be reached. At this manifold pressure (1.98 bar) the ECM will discontinue any injector pulses until the pressure drops to 1.6 bar.

If the WASTE GATE SOLENOID VALVE or control circuit were to fail in a 0% duty cycle mode, the boost pressure will only reach 1.55 bar.

The "WASTE GATE duty cycle" of the WASTE GATE SOLENOID VALVE is stored in the PROM/MEMCAL of the ECM. The "WASTE GATE BLOCK LEARN MEMORY" is a portion of ECM memory used to make long-term corrections to conditions of the engine. Further information about "WASTE GATE BLOCK LEARN MEMORY" in test step 18.

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes										
17	WASTE GATE D.C.	Engine at idle, operating temp.	100 % or 0 % but not between !!	16, 66										
Trouble-shooting: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; vertical-align: top;"> <ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Measure voltage between Waste Gate Solenoid Ter."A" and ground.</li> <li>&gt; 11.0 V</li> </ul> </td> <td style="width: 50%; vertical-align: top;">           Cause of Fault: (If nominal values NOT attained)           <ul style="list-style-type: none"> <li>o Fuse SOLENOIDS blown.</li> <li>o Short to ground or open in CKT between Fuse SOLENOIDS and Waste Gate Solenoid Ter."A".</li> </ul> </td> </tr> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Disconnect Waste Gate Solenoid plug.</li> <li>Measure voltage between Waste Gate Solenoid Ter."B" and ground.</li> <li>&gt; 11.0 V</li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Short to ground or open in CKT between ECM plug Ter."J4-D10" and Waste Gate Solenoid Ter."B".</li> <li>o ECM defective</li> </ul> </td> </tr> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Measure voltage between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>Drive car on road. ~ 30 mph (50 km/h)</li> <li>4-th gear. Accelerator in WOT position for less than 5 seconds.</li> <li>&gt; 1.0 V</li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o ECM defective.</li> </ul> </td> </tr> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Measure resistance between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>28 to 35 <math>\Omega</math></li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Waste Gate Solenoid defective.</li> </ul> </td> </tr> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o Reconnect Waste Gate Solenoid</li> <li>Waste Gate Valve OK</li> </ul> </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> <li>o See test step 17 part 2</li> </ul> </td> </tr> </table>					<ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Measure voltage between Waste Gate Solenoid Ter."A" and ground.</li> <li>&gt; 11.0 V</li> </ul>	Cause of Fault: (If nominal values NOT attained) <ul style="list-style-type: none"> <li>o Fuse SOLENOIDS blown.</li> <li>o Short to ground or open in CKT between Fuse SOLENOIDS and Waste Gate Solenoid Ter."A".</li> </ul>	<ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Disconnect Waste Gate Solenoid plug.</li> <li>Measure voltage between Waste Gate Solenoid Ter."B" and ground.</li> <li>&gt; 11.0 V</li> </ul>	<ul style="list-style-type: none"> <li>o Short to ground or open in CKT between ECM plug Ter."J4-D10" and Waste Gate Solenoid Ter."B".</li> <li>o ECM defective</li> </ul>	<ul style="list-style-type: none"> <li>o Measure voltage between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>Drive car on road. ~ 30 mph (50 km/h)</li> <li>4-th gear. Accelerator in WOT position for less than 5 seconds.</li> <li>&gt; 1.0 V</li> </ul>	<ul style="list-style-type: none"> <li>o ECM defective.</li> </ul>	<ul style="list-style-type: none"> <li>o Measure resistance between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>28 to 35 <math>\Omega</math></li> </ul>	<ul style="list-style-type: none"> <li>o Waste Gate Solenoid defective.</li> </ul>	<ul style="list-style-type: none"> <li>o Reconnect Waste Gate Solenoid</li> <li>Waste Gate Valve OK</li> </ul>	<ul style="list-style-type: none"> <li>o See test step 17 part 2</li> </ul>
<ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Measure voltage between Waste Gate Solenoid Ter."A" and ground.</li> <li>&gt; 11.0 V</li> </ul>	Cause of Fault: (If nominal values NOT attained) <ul style="list-style-type: none"> <li>o Fuse SOLENOIDS blown.</li> <li>o Short to ground or open in CKT between Fuse SOLENOIDS and Waste Gate Solenoid Ter."A".</li> </ul>													
<ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Disconnect Waste Gate Solenoid plug.</li> <li>Measure voltage between Waste Gate Solenoid Ter."B" and ground.</li> <li>&gt; 11.0 V</li> </ul>	<ul style="list-style-type: none"> <li>o Short to ground or open in CKT between ECM plug Ter."J4-D10" and Waste Gate Solenoid Ter."B".</li> <li>o ECM defective</li> </ul>													
<ul style="list-style-type: none"> <li>o Measure voltage between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>Drive car on road. ~ 30 mph (50 km/h)</li> <li>4-th gear. Accelerator in WOT position for less than 5 seconds.</li> <li>&gt; 1.0 V</li> </ul>	<ul style="list-style-type: none"> <li>o ECM defective.</li> </ul>													
<ul style="list-style-type: none"> <li>o Measure resistance between Waste Gate Solenoid Ter."B" and Ter."A"</li> <li>28 to 35 <math>\Omega</math></li> </ul>	<ul style="list-style-type: none"> <li>o Waste Gate Solenoid defective.</li> </ul>													
<ul style="list-style-type: none"> <li>o Reconnect Waste Gate Solenoid</li> <li>Waste Gate Valve OK</li> </ul>	<ul style="list-style-type: none"> <li>o See test step 17 part 2</li> </ul>													




4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
17 Part - 2	WASTE GATE D.C.	Engine at Idle, operating temp.	100 % or 0 % but not between !!	16, 66

o Checking Procedure Turbocharger Wastegate Preload:

- 1) Remove hose "4" and apply a pressure of 8 psi  $\pm$  0.25 psi ( 0.55 .. 0.57 bar). !! Do not apply more than 10 psi ( 0.69 bar) as this may damage the diaphragm.
- 2) Measure movement of rod end "5" using a DTI (Micrometer) this should be between 0.010" .. 0.020" (0.25..0.5 mm) ( Kent-moore tool No: J 800/1 )
- 3) Ensure the DTI is normal to the rod end.
- 4) Check each turbocharger individually. Should one or both turbochargers be out of specification, reset the preload to the following procedure.  
See test step 17 part 3



4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
17	WASTE GATE D.C.	Engine at idle, operating temp.	100 & or 0 & but not between !!	16, 66


Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

o Setting Procedure Turbocharger WASTE GATE Preload:

- 1) Apply pressure of 8 psi  $\pm$  0.5 psi to "4".
- 2) Stacken off locknut "3"
- 3) Remove retaining clip "2"
- 4) Pull actuator rod off pin on crank "6".
- 5) Push crank "6" towards actuator while maintaining pressure, screw actuator rod end "7" in or out to engage on the crank pin. The rod shod be as short as possible, so that the rod eye just engages on the pin without forcing
- 6) Fit retaining clip "2"
- 7) Tigthten locknut "3" to 7 Nm
- 8) Relieve pressure to port "4"
- 9) Check settings using "checking procedure"  
See test step 17 page 2.



4.4 F0: DATA LIST

Test Step	TECH 1 -- Display	Notes	Nominal Values	Possible Trouble Codes
18	WASTE GATE BLM	Engine at idle, operating temp.	-5 % .. +5 %	16, 66

The 'WASTE GATE BLOCK LEARN MEMORY' is a portion of ECM memory used to make long-term corrections to desired boost pressure. This correction is to compensate the small manufacturing tolerances and/or normal aging of parts in each of the various system components.

The ECM has a memory portion of 16 cells to modify the above mentioned tolerances.

For example: If the MAP-Sensor detects a boost pressure greater or less than stored in the PROM/MEMCAL for this engine speed and load, the concerning WASTE GATE BLOCK LEARN MEMORY cell will be updated. Following this update, the WASTE GATE SOLENOID duty cycle will be modify to prevent under- or overboost.

Attention : The content of the WASTE GATE BLOCK LEARN MEMORY cell is not identical to the WASTE GATE SOLENOID VALVE duty cycle. The content will only be used to modify this WASTE GATE SOLENOID VALVE duty cycle.

Content of the WASTE GATE BLOCK LEARN MEMORY cells below only for example.

(+4 % ) cell 09	(+3 % ) cell 10	(+2 % ) cell 11	(+1 % ) cell 12	( 0 % ) cell 13	(-1 % ) cell 14	(-2 % ) cell 15	(-4 % ) cell 16
Engine speed ---->							
4000-4500	4500-5000	5000-5500	5500-6000	6000-6500	6500-7000	7000-7500	7500-8000 RPM
( 0 % ) cell 01	(-6 % ) cell 02	(+1 % ) cell 03	(-2 % ) cell 04	(-3 % ) cell 05	(+5 % ) cell 06	(+6 % ) cell 07	(+5 % ) cell 08
Engine speed ---->							
0-500	500-1000	1000-1500	1500-2000	2000-2500	2500-3000	3000-3500	3500-4000 RPM

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
19	FRONT O2 SENSOR	Engine at idle, operating temp. AC-switch OFF.	READY	13, 44, 45
Trouble-shooting:				
<ul style="list-style-type: none"> <li>o Check connection between ECM "J1-A21" and front O2-Sensor Ter."C"</li> </ul>		Nominal Value: Continuity, < 1 Ω	Cause of Fault: (If nominal values NOT attained) o cable interruption	
<ul style="list-style-type: none"> <li>o Check connection between ECM "J3-C15" and front O2-Sensor Ter."A"</li> </ul>		Continuity, < 1 Ω	o cable interruption	
<ul style="list-style-type: none"> <li>o Ignition ON Measure voltage on front O2-Sensor Ter."B" to ground. Using Multimeter. (20V/DC)</li> </ul>		> 11 V	o Ignition fuse blown o short to ground between ignition fuse "I" and O2-Sensor Ter."B".	
<ul style="list-style-type: none"> <li>o Check connection between Ignition fuse "I" and front O2-Sensor Ter."B" (reconnect fuse)</li> </ul>		Continuity, < 1 Ω	o Cable interruption between ignition fuse "I" and O2-Sensor Ter."B".	
<ul style="list-style-type: none"> <li>o Check connection between ground and front O2-Sensor Ter."D"</li> </ul>		Continuity, < 1 Ω	o cable interruption	
<ul style="list-style-type: none"> <li>o See test step 23</li> </ul>				

4.4 F0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
20	REAR O2 SENSOR	Engine at Idle, operating temp. AC-switch OFF.	READY	63, 64, 65
<b>Trouble-shooting:</b>				
<b>Nominal Value:</b>				
<b>Cause of Fault:</b> (If nominal values NOT attained)				
o Check connection between ECM "J3-C20" and rear O2-Sensor Ter."C"				
o Check connection between ECM "J1-A16" and rear O2-Sensor Ter."A"				
o Ignition ON Measure voltage on rear O2-Sensor Ter."B" to ground. Using Multimeter. (20V/DC)				
o Check connection between Ignition fuse "I" and rear O2-Sensor Ter."B" (reconnect fuse)				
o Check connection between ground and rear O2-Sensor Ter."D"				
o See test step 25				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
21	TIME FROM START	Ignition ON Start engine Engine at idle speed	00:00:00 > 00:00:00	


**NOTE:**  
This test step serves as a learning and checking value to understand the system better and to evaluate the system on external influences.

By using the TECH 1 keys P1 and/or P2 one of the TECH 1 displayed test steps will be frozen. The other test step can be changed by using the arrow keys.

**Trouble-shooting:**

- o Ignition OFF
- o Ignition ON
- o Start engine
- o Engine at idle speed

**Nominal Value:**



**Cause of Fault:**  
(If nominal values NOT attained)

- o If engine run timer doesn't work and some other test steps don't work correct follow directions below:  
Remove and re-install PROM/MEMCAL. Ensuring that latches are secured properly. Retest test step 21. If problem is still present replace PROM/MEMCAL. Retest test step 21. If problem is still exists replace ECM.
- o If only engine run timer doesn't work go to test step 22.

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
22	O2 SENSOR LOOP	Ignition ON. Start engine. Engine at idle speed. Operating temperature.	OPEN CLOSED	
<b>Trouble-shooting:</b>				
<b>Nominal Value:</b>				
<b>Cause of Fault:</b> (If nominal values NOT attained)				
o Engine at idle speed		No trouble code set	o Repair system	
o Engine at idle speed		TRCH 1 display shows: CLOSED	o See test step 19	
o Engine at idle speed		test step 19 OK	o See test step 20	
o Engine at idle speed		test step 20 OK	o See test step 05, 07, 36	
o Engine at idle speed		test steps OK	o if test step 22 doesn't work and all other test steps are OK, then follow directions below:	
<p>Remove and re-install PROM/MEMCAL Ensuring that latches secured properly. Retest test step 22. If problem is still ahead replace PROM/MEMCAL. Retest test step 22. If problem is still ahead replace ECM.</p>				
<p>o if test step 22 doesn't work and some other test steps don't work correct then repair system first.</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
23	FRONT O2 SENSOR	Ignition ON Start engine Engine at Idle speed	400 to 460 mV 50 to 950 mV	13, 44, 45
Trouble-shooting:				
Nominal Value: Cause Fault: (If nominal values NOT attained)				
<ul style="list-style-type: none"> <li>o Ignition ON</li> <li>Go to test step 19 first</li> <li>Test step 19 OK</li> <li>Repair sensor wiring harness.</li> </ul>				
<ul style="list-style-type: none"> <li>o Disconnect front O2-Sensor.</li> <li>Measure voltage between O2-Sensor plug (ECM-side) Ter."A" and ground.</li> <li>TRCH 1 display: 400 to 460 mV</li> <li>Multimeter display: 400 to 460 mV</li> <li>o If test step 19 OK, repeat measure between ECM Ter. J3-C15 and ground. If not OK then ECM defective. else temporary interruption in wiring harness.</li> </ul>				
<ul style="list-style-type: none"> <li>o Connect Adapter Cable KM-609 and reestablish connection between ECM and O2-Sensor except line "A".</li> <li>TRCH 1 display: 50 to 950 mV</li> <li>Multimeter display: 50 to 950 mV</li> <li>o If control loop closes only very slowly - Oxygen Sensor heater defective.</li> <li>o Oxygen Sensor defective.</li> <li>o Mixture always to rich (see test step 23 part 02)</li> <li>o Mixture always to lean (see test step 23 part 03)</li> <li>o ECM defective.</li> </ul>				
<ul style="list-style-type: none"> <li>o Measure voltage between Ter."A" of the O2-Sensor plug (O2-Sensor side) to ground.</li> <li>Start engine.</li> <li>Engine at Idle speed.</li> </ul>				
* See terminal assignments in section 6				



4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
23	FRONT O2 SENSOR	Ignition ON Start engine Engine at idle speed	400 to 460 mV 50 to 950 mV	13, 44, 45
Part - 2				

Trouble-shooting:

Nominal Values:

Cause of Fault:  
(If nominal values NOT attained)

- o Mixture always rich.  
(Oxygen sensor voltage > 600 mV)
  - Connect Manometer KM-J-34730-1 to test fuel pressure test point.
  - In addition
    - Slowly open fuel connection valve to fuel rail to reduce pressure in system
    - Connect second manometer to return (use T-adapter)
    - Bleed manometer before measuring
    - Start engine and allow to run
    - Remove vacuum hose from pressure regulator
  - Pressure in feed : 3.0 ± 0.2 bar
  - Pressure in return : 0.3 to 1.5 bar
  - o Install vacuum hose : Pressure must fall by 0.4 to 0.6 bar
  - o Ignition OFF, Reconnect ECM-plug "J1" and inj.-valves and measure resistance between injector plugs (female) and ground.
- 
- o Fuel pressure to high
  - o Pressure regulator defective
  - o Return line blocked or kinked
  - o Vacuum hose to pressure regulator leaky
  - o splash baffle in fuel tank blocked
- Further Causes of Faults:
- o Charcoal canister purge solenoid open
  - o Charcoal canister or line leaky
  - o Leaky Injectors :
    - o cylinder 1, 2 or 3
  - o CT-Sensor defective (see test step 07)
  - o MAP-Sensor not linear (see test step 09)
  - o BP-Sensor defective (see test step 10)
- 
- o Line between Injector 1 and J1-A3 or Injector 2 and J1-A12 or Injector 3 and J1-A7 temporary or permanent short to ground.
  - o ECM defective

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
23 Part - 3	FRONT O2 SENSOR	Ignition ON Start engine Engine at idle speed	400 to 460 mV 50 to 950 mV	13, 44, 45
<p><b>Trouble-shooting:</b></p> <p style="text-align: center;"><b>Nominal Value:</b></p>				
<p>o Mixture always lean. (Oxygen sensor voltage &lt; 300 mV)</p> <p>Connect Manometer KM-J-34730-1 to test fuel pressure test point. In addition</p> <ul style="list-style-type: none"> <li>- Slowly open fuel course connection to distributor pipe to reduce pressure in system</li> <li>- Connect second manometer to return (use T-adapter)</li> <li>- Bleed manometer before measuring</li> <li>- Start engine and allow to run</li> <li>- Remove vacuum hose from pressure regulator</li> </ul> <p>Pressure in feed : 3.0 ± 0.2 bar Pressure in return : 0.3 to 1.5 bar</p> <p>o Install vacuum hose : Pressure must fall by 0.4 to 0.6 bar</p> <p>o Ignition OFF, Reconnect ECM-plug "J1" and injector plugs and measure resistance between injector plugs (female) and U-batt. &gt; 20 kΩ</p>				
<p><b>Cause of Fault:</b> (If nominal values NOT attained)</p> <ul style="list-style-type: none"> <li>o Fuel pressure too low</li> <li>o Fuel pump defective (see test step 02)</li> <li>o splash baffle in fuel tank loose</li> <li>o Pressure regulator defective</li> <li>o Fuel filter dirty</li> <li>o Check fuel pump supply (see Technical Data)</li> </ul> <p>Further Causes of Faults:</p> <ul style="list-style-type: none"> <li>o Injectors : cylinder 1, 2 or 3 defective</li> <li>o CT-Sensor defective (see test step 07)</li> <li>o MAP-Sensor not linear (see test step 09)</li> <li>o Baro-sensor defective (see test step 10)</li> <li>o Poor fuel quality</li> <li>o Exhaust system leaky</li> <li>o ECM defective</li> </ul> <p>o Line between Injector 1 and J1-A3 or Injector 2 and J1-A12 Injector 3 and J1-A7 temporary or permanent short to U-batt.</p>				

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
24	FRONT O2 INT.	Ignition ON Start engine Engine at idle speed	128 STEPS 123 to 133 STEPS	13, 44, 45

In the discussion below the "front part" of engine refer to cylinders Nr. 1, 2, and 3 and the corresponding (front) O2-sensor and O2-integrator.

The tendency (rich or lean mixture) of the front oxygen sensor regulation can be evaluated with FRONT O2 INT.

If for example the intake air/fuel mixture is too lean (actual value > 133 STEPS), the value of FRONT O2 INT. and thereby the injection timing increased in stages until the oxygen sensor signals too rich a mixture. The integrator is subsequently reduced again. ( closed loop )

Integrator = 128 STEPS : Mixture stoichiometric. That means, for 14.7 active materials of air is 1 active material of fuel available.

or : System goes to open loop in the front part of the engine.  
The FRONT O2 INT. is frozen to 128 because either the conditions for closed loop are not reached or the system detected a malf-code.

NOTE : If the system goes closed loop and no fault is detected, the FRONT O2 INT. fluctuate between 120 and 135.

> 128 STEPS : Mixture too lean, Injection timing is increased.

< 128 STEPS : Mixture too rich, Injection timing is decreased.

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
24 Part - 2	FRONT 02 INT.	Ignition ON Start engine Engine at Idle speed	128 STEPS 123 to 133 STEPS	13, 44, 45

Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

o In order to be able to determine a change in the FRONT 02 INT. the FRONT 02 BIM correction must be used. See also test step 28 02 BIM CELL NO.

o Brake trouble code.

1. FRONT 02 INT. > 133 and FRONT 02 BIM < 128 than : wait a few minutes for system stabilisation
2. FRONT 02 INT. > 133 and FRONT 02 BIM > 145 than : See test step 23 part 3  
Mixture always lean.  
(Oxygen sensor voltage < 300 mV)
3. FRONT 02 INT. < 123 and FRONT 02 BIM > 128 than : wait a few minutes for system stabilisation
4. FRONT 02 INT. < 123 and FRONT 02 BIM < 110 than : See test step 23 part 2  
Mixture always rich.  
(Oxygen sensor voltage > 600 mV)

4.4 P0: DATA LIST

Test Step	TBCH 1 -- Display	Notes	Nominal Values	Possible Trouble Codes
25	REAR O2 SENSOR	Ignition ON Start engine Engine at idle speed	400 to 460 mV 50 to 950 mV	63, 64, 65
<p><b>Trouble-shooting:</b></p> <p style="text-align: center;">Nominal Values: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Ignition ON</p> <p>Go to test step 20 first</p> <p style="text-align: center;">Test step 20 OK</p> <p>o Repair sensor wiring harness.</p>				
<p>o Disconnect front O2-Sensor.</p> <p>Measure voltage between O2-Sensor plug (ECM-side) Ter. "A" and ground.</p> <p style="text-align: center;">TBCH 1 display: 400 to 460 mV Multimeter display: 400 to 460 mV</p> <p>o If test step 20 OK, repeat measure between ECM Ter. J1-A16 and ground. If not OK then ECM defective. else temporary interruption in wiring harness.</p>				
<p>o Connect Adapter Cable KM-609 and reestablish connection between ECM and O2-Sensor except line "A".</p> <p>Measure voltage between Ter. "A" of the O2-Sensor plug (O2-Sensor side) to ground. Start engine. Engine at idle speed.</p> <p style="text-align: center;">TBCH 1 display: 50 to 950 mV Multimeter display: 50 to 950 mV</p> <p>o If control loop closes only very slowly - Oxygen Sensor heater defective.</p> <p>o Oxygen Sensor defective.</p> <p>o Mixture always too rich (see test step 25 part 02)</p> <p>o Mixture always too lean (see test step 25 part 03)</p> <p>o ECM defective.</p>				

\* See terminal assignments in section 6

4.4 P0: DATA LIST

Test Step	TRCH 1 -- Display	Notes	Nominal Values	Possible Trouble Codes
25	REAR O2 SENSOR Part - 2	Ignition ON Start engine Engine at Idle speed	400 to 460 mV 50 to 950 mV	63, 64, 65
<p>Trouble-shooting: <span style="float: right;">Nominal Value:</span></p> <p>o Mixture always rich. (Oxygen sensor voltage &gt; 600 mV)</p> <p>Connect Manometer KM-J-34730-1 to test fuel pressure test point. In addition</p> <ul style="list-style-type: none"> <li>- Slowly open fuel connection valve to the fuel rail to reduce pressure in system</li> <li>- Connect second manometer to return (use T-adapter)</li> <li>- Bleed manometer before measuring</li> <li>- Start engine and allow to run</li> <li>- Remove vacuum hose from pressure regulator</li> </ul> <p>Pressure in feed : 3.0 ± 0.2 bar Pressure in return : 0.3 to 1.5 bar o Install vacuum hose : Pressure must fall by 0.4 to 0.6 bar</p> <p>o Ignition OFF, Reconnect ECM-plug "J1" and injector plugs and measure resistance between injector plugs (female) and ground.</p>				
<p>Cause of Fault: (If nominal values NOT attained)</p> <ul style="list-style-type: none"> <li>o Fuel pressure to high</li> <li>o Pressure regulator defective</li> <li>o Return line blocked or kinked</li> <li>o Vacuum hose to pressure regulator leaky</li> <li>o splash baffle in fuel tank blocked</li> </ul> <p>Further Causes of Faults:</p> <ul style="list-style-type: none"> <li>o Charcoal canister purge solenoid open</li> <li>o Charcoal canister or line leaky</li> <li>o Leaky Injectors :               <ul style="list-style-type: none"> <li>o Cylinder 4, 5 or 6</li> </ul> </li> <li>o CT-Sensor defective (see test step 07)</li> <li>o MAP-Sensor not linear (see test step 09)</li> <li>o Baro-sensor defective(see test step 10)</li> </ul>				
<p>o Line between Injector 4 and J1-A8 or Injector 5 and J1-A2 Injector 6 and J1-A1 temporary or permanent short to ground. o ECM defective</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
25	REAR O2 SENSOR	Ignition ON Start engine Engine at idle speed	400 to 460 mV 50 to 950 mV	63, 64, 65
<p>Part - 3</p> <p>Trouble-shooting:</p> <p>Nominal Value:</p> <p>Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Mixture always lean. (Oxygen sensor voltage &lt; 300 mV)</p> <p>Connect Manometer KM-J-34730-1 to test fuel pressure test point. In addition</p> <ul style="list-style-type: none"> <li>- Slowly open fuel course connection to distributor pipe to reduce pressure in system</li> <li>- Connect second manometer to return (use T-adapter)</li> <li>- Bleed manometer before measuring</li> <li>- Start engine and allow to run</li> <li>- Remove vacuum hose from pressure regulator</li> </ul> <p>Pressure in feed : 3.0 ± 0.2 bar Pressure in return : 0.3 to 1.5 bar</p> <p>o Install vacuum hose : Pressure must fall by 0.4 to 0.6 bar</p> <p>o Ignition OFF, Reconnect ECM-plug "J1" and injector plugs and measure resistance between injector plugs (female) and U-batt. &gt; 20 kΩ</p> <p>o Fuel pressure too low</p> <ul style="list-style-type: none"> <li>• Fuel pump defective (see test step 02)</li> <li>• splash baffle in fuel tank loose</li> <li>• Pressure regulator defective</li> <li>• Fuel filter dirty</li> <li>• Check fuel pump supply (see Technical Data)</li> </ul> <p>Further Causes of Faults:</p> <ul style="list-style-type: none"> <li>• Injectors : cylinder 4, 5 or 6 defective</li> <li>• CT-Sensor defective (see test step 07)</li> <li>• MAP-Sensor not linear (see test step 09)</li> <li>• Baro-sensor defective(see test step 10)</li> <li>• Poor fuel quality</li> <li>• Exhaust system leaky</li> </ul> <p>o BCM defective</p> <p>o Line between Injector 4 and J1-A8 or Injector 5 and J1-A2 or Injector 6 and J1-A1 temporary or permanent short to U-batt.</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
26	RRAR 02 INT.	Ignition ON Start engine Engine at Idle speed	128 STEPS 123 to 133 STEPS	63, 64, 65

In the discussion below the "rear part" of engine refer to cylinders Nr. 4, 5, and 6 and the corresponding (rear) O2-sensor.

The tendency (rich or lean mixture) of the rear oxygen sensor regulation can be evaluated with RRAR 02 INT.

If for example the intake air/fuel mixture too lean (actual value > 133 STEPS), the value of RRAR 02 INT. and thereby the injection timing increased in stages until the oxygen sensor signals too rich a mixture. The integrator is subsequently reduced again. ( closed loop )

Integrator = 128 STEPS : Mixture stoichiometric. That means, for 14.7 active materials of air is 1 active material of fuel available.

or : System goes to open loop in the front part of the engine.  
The RRAR 02 INT. is frozen to 128 because either the conditions for closed loop are not reached or the system detected a malf-code.

NOTE : If the system goes closed loop and no fault is detected, the RRAR 02 INT. fluctuate between 120 and 135.

> 128 STEPS : Mixture too lean, Injection timing is increased.

< 128 STEPS : Mixture too rich, Injection timing is decreased.



4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
26	REAR O2 INT.	Ignition ON Start engine Engine at idle speed	128 STEPS 123 to 133 STEPS	63, 64, 65

Trouble-shooting:

Nominal Value:

Cause of Fault:  
(If nominal values NOT attained)

o In order to be able to determine a change in the REAR O2 INT. the REAR O2 BLM correction must be used. See test step 28 O2 BLM CELL NO.

o Erase trouble code.

1. REAR O2 INT. > 133 and REAR O2 BLM < 128 than : wait a few minutes for system stabilisation
2. REAR O2 INT. > 133 and REAR O2 BLM > 145 than : See test step 25 part 3  
Mixture always lean.  
(Oxygen sensor voltage < 300 mV)
3. REAR O2 INT. < 123 and REAR O2 BLM > 128 than : wait a few minutes for system stabilisation
4. REAR O2 INT. < 123 and REAR O2 BLM < 110 than : See test step 25 part 2  
Mixture always rich.  
(Oxygen sensor voltage > 600 mV)


4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
27	02 BIM ENABLE	Engine at Idle, operating temp. AC-switch OFF. Switch OFF all consumers.	ACTIVE	13, 44, 45, 63, 64, 65
<p>Trouble-shooting: Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o If the 02 BIM ENABLE is INACTIVE with engine idling at operating temperature, the following test steps should be checked in acc. with fast check list:</p>				
Test step No.:		Checking of	Test step No.:	
03	ENGINE SPEED		09	MAP SENSOR
05	RPS SIGNAL		10	BAROMETR SENSOR
07	COOLANT TEMP.		19	FRONT 02 SENSOR
08	MAT SENSOR		20	REAR 02 SENSOR
			22	02 SENSOR LOOP
<p>o Engine at Idle speed test steps OK</p> <p>o If test step 27 doesn't work and all other test steps are OK, then follow directions below:</p> <p>Remove and re-install PROM/MEMCAL. Ensuring that latches secured properly. Retest test step 27. If problem is still present replace PROM/MEMCAL. Retest test step 27. If problem is still exists replace ECM.</p> <p>o If test step 27 doesn't work and some other test steps don't work correct then repair system first.</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
28	O2 BIM CELL NO.	Engine at idle speed Engine speed > 2000 RPM MAP-Sensor > 0.65 bar	0 > 0	

Block learn, also called Block Learn Memory, or BIM is a portion of ECM memory used to make long-term corrections to fuel delivery across all operating conditions of the engine. This correction is to compensate for small manufacturing tolerances and/or normal aging of parts in each of the various system components. The ECM reserves memory locations for various load conditions of the engine specified by MAP and RPM. Each location represents a "block" or "cell", or specific operating condition of the engine. Some systems use more cells, while others use as few as two - idle and off-idle. This two cell system is used in Motronic or IRFI-Multec ECM's. In this case, we have two groups of cells each with 16 cells.



The values in the brackets are the Block-Learn-Memory values for example. The values in the front BLOCK LEARN CELLS are OK. The values in the Rear BLOCK LEARN CELLS are also OK, but maybe a leak is in the exhaust system for cylinder 4, 5 or 6 between cylinder head and exhaust pipe. In this case only the cells No.: 0, 1, 4 and 5 are affected. For further info. see LOTUS/OMEGA Training.

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
29	FRONT O2 BLM	Ignition ON Start engine Engine at idle speed	128 STEPS 110 to 145 STEPS	43, 44, 45

**NOTE:** In the discussion below the "front part" of engine refer to cylinders Nr. 1, 2, and 3 and the corresponding front O2-Sensor, the front O2-Integrator and front O2-Block learn memory.

Via front O2-Block learn memory (FRONT O2 BLM), learned deviations from the ideal mixture conditions (e.g. by air leakage in front part of the engine) are captured by the control unit (ECM) and stored in the permanent memory. This memory is a long term memory, so that the corrected values are available also after the supply voltage has been switched off and the engine re-started. With front O2-Block learn memory an evaluation of the learned values of the system can be made.

In each part (front and rear) of the engine are 16 Block learn cells available. Which cell will be modified depends of the actual engine speed and load.  
For idle select in test step 28 the cell No.: 0

In order to be able to evaluate the deviation of the front O2-Block learn memory (FRONT O2 BLM) the front O2-Integrator must be observed.

Trouble-shooting:

Nominal Values: Cause of Fault:  
(If nominal values NOT attained)

- o Ignition ON
- Select cell No.: 0                      128 STEPS                      o See test step 24 part 2
- Start engine
- Engine at idle speed                      110 to 145 STEPS

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
30	RRAR 02 BIM	Ignition ON Start engine Engine at idle speed	128 STEPS 110 to 145 STEPS	63, 64, 65

**NOTE:** In the discussion below the "rear part" of engine refer to cylinders Nr. 4, 5, and 6 and the corresponding (rear) O2-Sensor, the rear O2-Integrator and rear O2-Block learn memory.

Via rear O2-Block learn memory (RRAR 02 BIM), learned deviations from the ideal mixture conditions (e.g. by air leakage in rear part of the engine) are captured by the control unit (ECM) and stored in the permanent memory. This memory is a long term memory, so that the corrected values are available also after the supply voltage has been switched off and the engine re-started. With rear O2-Block learn memory an evaluation of the learned values of the system can be made.

In each part (front and rear) of the engine are 16 Block learn cells available. Wich cell will be modified depends of the actual engine speed and load.  
For Idle select in test step 28 the cell No.: 0

In order to be able to evaluate the deviation of the rear O2-Block learn memory (RRAR 02 BIM) the rear O2-Integrator must be observed.

**Trouble-shooting:**  
**Nominal Value:**  
**Cause of Fault:**  
(If nominal values NOT attained)

- o Ignition ON
  - Select cell No.: 0
  - Start engine
  - Engine at idle speed
- 128 STRPS
- 110 to 145 STRPS
- o See test step 26 part 2

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
31	CANISTER PURGE	Ignition ON Start engine Engine at Idle speed Engine speed out of Idle,TPS >4%	0% >1%	
<p><b>Trouble-shooting:</b></p> <p style="text-align: center;">Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Ignition ON Measure voltage at Charcoal canister purge solenoid Ter."A"</p> <p style="text-align: center;">11.5 to 13.5 V</p> <p>o lead Interruption from Ignition "Y" fuse (Solenoids) to charcoal can. sol. OR Ignition "Y" fuse blown</p> <p>o lead Interruption between ECM "J3-C10" and Charcoal canister purge solenoid Ter."B"</p>				
<p>o Ignition ON Start engine Engine at Idle speed * Engine speed out of Idle,TPS &gt;4%      1 to 13.5 V</p> <p>Measure voltage between Charcoal canister purge solenoid Ter."A" and Ter."B"</p> <p>o C.C.Solenoid defective</p> <p>o ECM defective</p>				
<p>o Ignition OFF Reconnect C.C.Solenoid Measure resistant between Ter."A" and "B" at C.C.Solenoid</p> <p style="text-align: center;">xx to yy Ω</p> <p>* Drive on steet ~ 30 mph (50km/h) constantl.</p>				

4.4 FO: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
32	FAN STATUS	Ignition ON Start engine, Engine at idle speed Coolant temperature > 97°C, 207°F	OFF 12 V ON 0 V	
<p>Trouble-shooting: Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Ignition ON &gt; 11.0 V o Line interrupt between ECM J3-C6 and FAN RELAY COIL Ter. (color "NW") or A/C INTERFACE Connector faulty or A/C HIGH PRESS. SW. closed or Line interrupt between Fuse FL13 and FAN RELAY COIL Ter. (color "R")</p>				
<p>o Disconnect A/C INTERFACE Con. &gt; 11.0 V o Line interrupt between Fuse "FL22" and A/C INTERFACE Connector Ter. "E"</p>				
<p>o Measure Voltage between A/C INTERFACE Con. (female) Ter. "E" and ground.</p>				
<p>o Measure resistance between A/C INTERFACE Con. (female) Ter. "G" and FAN RELAY &lt; 2 <math>\Omega</math> o Line interrupt between FAN RELAY and A/C INTERFACE Connector Ter. "G"</p>				
<p>o Measure resistance between A/C INTERFACE Con. (male) Ter. "E" and "G" 0.4..0.9 <math>\Omega</math> o FAN defective Line interrupt between A/C INTERFACE Con. Ter. "G" and FAN or A/C INTERFACE Con. Ter. "E" and FAN.</p>				
<p>o Reconnect A/C INTERFACE Con. Jumper Relay connector Ter. (color "N 2.5" to "N 2.5") FAN is running o Line interrupt between Relay con. and ground.</p>				

4.4 FO: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
33	A/C REQUEST SW.	Engine at idle speed AC-switch OFF AC-switch ON	OFF 0 V ON 12 V	
<p><b>Trouble-shooting:</b></p> <p style="text-align: center;">Nominal Value:</p>				
<p><b>Cause of Fault:</b> (If nominal values NOT attained)</p> <ul style="list-style-type: none"> <li>o Disconnect the A/C Interface. Jumper Ter. X7 "B" (ECM side) to 12 V. (engine idling) <ul style="list-style-type: none"> <li>TECH 1 display: AC-switch ON</li> </ul> </li> <li>o Line interrupt or short to ground between X7" B" and ECM J3-C6 <ul style="list-style-type: none"> <li>HIGH PRESS.SW. open</li> <li>LOW PRESS.SW. open.</li> <li>ECM defective.</li> </ul> </li> <li>o Engine run relay K .. not energized or defective. <ul style="list-style-type: none"> <li>Fuse F12 blown.</li> <li>Line interrupt between relay K .. and A/C switch</li> <li>between relay K .. and Fuse F12 between alternator Ter."61" and relay K..coil.</li> <li>relay K..coil and ground.</li> </ul> </li> </ul>				
<ul style="list-style-type: none"> <li>o Remove jumper. Measure voltage between X7 "B" (A/C SW. side) and ground <ul style="list-style-type: none"> <li>Engine at idle speed 0 V</li> <li>AC-switch OFF 0 V</li> <li>AC-switch ON 12 V</li> </ul> </li> </ul>				





4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
35	AUX. WATER PUMP	Ignition ON Start engine, Engine at idle speed Coolant temperature > 93°C, 200°F Engine OFF, Ignition OFF	OFF 12 V ON 0 V	
Trouble-shooting:				
Nominal Values:				
Cause of Fault: (If nominal values NOT attained)				
o Measure voltage at HOT SOAK PUMP RELAY color "P" to ground.	11.5 to 13.5 V	o Lead Interruption between U-batt. and HOT SOAK PUMP RELAY.		
o open CRT between ECM "J3-C5" and HOT SOAK PUMP RELAY. (Disconnect ECM plug J3) Jumper harness ter. "J3-C5" (female) to ground.	HOT SOAK PUMP starts HOT SOAK PUMP SOLENOID works.	o HOT SOAK PUMP RELAY defective o HOT SOAK PUMP defective o HOT SOAK PUMP SOLENOID always short or lead interruption between o HOT SOAK PUMP RELAY and HOT SOAK PUMP o HOT SOAK PUMP and ground.	or between	
o Disconnect HOT SOAK PUMP RELAY. Measure resistance between ter. "J3-C5" (female) and HOT SOAK PUMP RELAY Plug	< 1 Ω	o Lead Interruption between HOT SOAK PUMP RELAY and ECM ter. "J3-C5"		
o Measure resistance between ter. "J3-C5" (female) and ground.	> 20 kΩ	o short to ground.		

4.4 P0: DATA LIST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
36	VEHICLE SPEED	Compare speedometer reading with TECH 1 value	Approx. same speed	24
<p>Trouble-shooting:</p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o Disconnect VEHICLE SPEED SENSOR plug. Measure Voltage between Ter. "A" and "B"</p> <p>&gt; 10 V o open or short to ground in CKT.</p>				
<p>o Disconnect ECM plug "J1" Measure resistance between J1-A6 and ground</p> <p>&gt; 20 kΩ o short to ground in CKT.</p>				
<p>o Measure resistance between J1-A6 and VEHICLE SPEED SENSOR plug Ter. "B"</p> <p>&lt; 1 Ω o open in CKT.</p>				
<p>o Disconnect ECM plug "J1" Measure resistance between J1-A11 and ground</p> <p>&gt; 20 kΩ o short to ground in CKT.</p>				
<p>o Measure resistance between J1-A11 and VEHICLE SPEED SENSOR plug Ter. "A"</p> <p>&lt; 1 Ω o open in CKT.</p>				
<p>o Measure resistance at VEHICLE SPEED SENSOR between plug Ter. "A" and "B"</p> <p>xx Ω o VEHICLE SPEED SENSOR defective</p> <p>o ECM defective</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
37	IGNITION STATUS	Ignition ON Start engine Engine at Idle speed	INVALID VALID	
<p><b>Trouble-shooting:</b></p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o See test step 03 test step 03 OK o repair system</p> <p>o Engine at Idle speed TRCH 1 display: o ECM defective means &gt; 700 RPM VALID</p>				

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
38	CAMSHAFT SIGNAL	Ignition ON Start engine Engine at idle speed	VALID	

Trouble-shooting:

Nominal Value:


Cause of Fault:  
(If nominal values NOT attained)

o Engine running at idle

CAM signal OK  
Mo Code 31

o See wave form: CAM-signal on  
Ter. "J4-D3"

- o CAM-sensor has no connection to +12 V
- o CAM-sensor has no connection to ground
- o Open or short CKT between CAM-sensor  
Ter. "B" and "J4-D3", color "NW"



Multimeter Voltage (20V/AC) ~ 1.35 - 1.55 V

- Further Causes of Faults:
- o CAM sensor defective.
  - o Segment disc/teeth corroded.
  - o Metal shavings on pulse pick-up.

4.4 P0: DATA LIST

Test Step	TRCH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
39	CONTROLLED IAC	Desired IAC step value Note: Select TRCH 1 Mode P6:ECM CONTROL and Submode P1:IAC CONTROL.	---- STEPS	
<p>Trouble-shooting: Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o The test step CONTROLLED IAC is only in TRCH 1 Mode P6:ECM CONTROL part P1:IAC CONTROL available. This test step can be used to examine the effect on the engine, when the IAC step value is greater or less than normal.</p> <p>. In this test step, the ECM instructs the IAC stepper motor to increase or decrease the step value until the desired step value is reached. The engine speed will follow.</p>				
<p>o Select Mode P6:ECM CONTROL Submode P1:IAC CONTROL TRCH 1 display: IX Steps o ECM defective or . see test step 06</p>				
<p>o Press arrow key 'up' step value and speed increases o see test step 06</p> <p>Press arrow key 'down' step value and speed decreases</p>				
<p>Note: The TRCH 1 P3:SNAPSHOT Mode is enabled.</p>				
<p>* If the Submode P1:IAC CONTROL is enabled by using the "YES" key, the displayed step value will be equal to the actual IAC Motor step rate. ! The TP-SENSOR signal must be 0% !</p>				

4.5 Table 1, Diagnostic Plug ALDL and Voltage Supply, Check

Test step	Tester Multimeter MKM-587-A	FRST		Notes	Nominal Value	Possible Cause of Fault, Trouble - shooting
		from	between			
1	Ohmmeter	Diagnostic plug (ALDL) ; ground	A ground	Ignition OFF	approx. 0 $\Omega$	<ul style="list-style-type: none"> <li>o Transfer resistance at grounding point too high.</li> </ul>
2	Voltmeter range: 20 V/DC	Diagnostic plug (ALDL) ; excitation lead	B ground	Ignition ON	> 5,0V	<ul style="list-style-type: none"> <li>o Lead interruption betw. ALDL ter. "B" and BCM ter. "J2-B2" or</li> <li>o BCM defective</li> </ul>
3	Voltmeter range: 20 V/DC	Diagnostic plug (ALDL) ; voltage supply (BCM power fuse)	F ground	Ignition ON	>11,0V	<ul style="list-style-type: none"> <li>o Battery voltage too low</li> <li>o Lead interruption betw. ALDL ter. "F" and BCM power fuse 7.5 AMP</li> </ul>
4	Voltmeter range: 20 V/DC	Diagnostic plug (ALDL) ; data lead	G ground	Ignition ON	> 4,0V	<ul style="list-style-type: none"> <li>o Lead interruption betw. ALDL ter. "G" and BCM ter. "J4-D15" .</li> <li>o BCM defective</li> </ul>

4.5 Table 1, Diagnostic Plug ALDL and Voltage Supply, Check

Test step	Tester Multimeter MM-587-A	TEST from	between	Notes	Nominal Value	Possible Cause of Fault, Trouble - shooting
5	-	Telltale H30	-	Ignition ON	Telltale ON > 11 V	<ul style="list-style-type: none"> <li>o Telltale H30 defective</li> <li>o Lead interruption betw. Telltale H30 and BCM ter. "J3-C11".</li> <li>o Lead interruption betw. Telltale H30 and fuse "Instrument panel"</li> <li>o short to batt. voltage</li> <li>o BCM defective</li> </ul>



4.5 Table 1, Diagnostic Plug ALDL and Voltage Supply, Check

Test step	Tester Multimeter MM-587-A	TEST From	TEST between	Notes	Nominal Value	Possible Cause of Fault, Trouble - shooting
6	-	TRCH 1 self test	-	See TRCH 1 Operating Instructions	-	
<p>Note. After test step 7 and 8 any trouble codes may be stored are deleted.</p>						
7	Ohmmeter	ECM plug J2 and J3 Ground	J2 - B6 J2 - B17 J3 - C12	GND Ignition OFF Disconnect ECM J2 and J3	ca. 0 Ω	<ul style="list-style-type: none"> <li>o Transfer resistance at grounding point too high</li> <li>o Lead interruption betw. and ground.</li> <li>o ECM defective</li> </ul>
8	Voltmeter range: 20 V/DC	ECM plug J2 Voltage supply	J2 - B8 J2 - B10 J2 - B11	GND Ignition ON	>11,5V	<ul style="list-style-type: none"> <li>o Battery voltage too low</li> <li>o See test step 01</li> </ul>

4.6 Table 2, Trouble Code Table

Trouble Code	Information sensor Cause of Fault	Remedy in P0:DATA L. Test Step	Trouble Code Storage when ...
13	TC 13: FRONT O2 SENSOR OPEN CIRCUIT	19 23	<p>In the discussion below the "front part" of engine refer to cylinders Nr. 1, 2, and 3 and the corresponding (front) O2-sensor.</p> <ul style="list-style-type: none"> <li>o O2 Signal voltage steady between 350 and 550 mV</li> <li>o Engine has been running longer than 2 minutes.</li> <li>o Engine coolant temperature greater than 69.5°C (158°F).</li> <li>o Throttle position sensor signal has been above 5% for 60 seconds or longer.</li> </ul> <p>. If the condition for code 13 exists the system will not go "Closed Loop" in the "front part" of the engine.</p>
14	TC 14: COOLANT TEMP. VOLTAGE LOW	07	<ul style="list-style-type: none"> <li>o Engine coolant temperature sensor signal voltage indicated a coolant temperature above 130°C (266°F).</li> <li>. If the condition for code 14 exists the system will take a default value (61°C, 142°F) instead of 130°C</li> </ul>
15	TC 15: COOLANT TEMP. VOLTAGE HIGH	07	<ul style="list-style-type: none"> <li>o Engine coolant temperature sensor signal voltage indicated a coolant temperature below -32°C (-26°F).</li> <li>. If the condition for code 15 exists the system will take a default value (61°C, 142°F) instead of -32°C</li> </ul>
16	TC 16: WASTE GATE OVERBOOST	09	<ul style="list-style-type: none"> <li>o Engine fuel cut off is indicated for a time greater than 3 seconds and a MAP is greater than 190 kPa.</li> <li>. If the code was once disabled, the re-enable time is 1 second.</li> </ul>

Table 2, Trouble Code Table

Trouble Code	Information sensor Cause of Fault	Remedy in P0:DATA L. Test Step	Trouble Code Storage when ...
21	TC 21: THROTTLE POSIT. SENSOR VOLTAGE HIGH	05	<ul style="list-style-type: none"> <li>o Engine has been running at idle and TPS signal voltage is greater than 2.56 volt for more than 2 seconds.</li> <li>OR</li> <li>o TPS signal voltage is greater than 4.80 volt.</li> <li>• If the condition for code 21 exists the system will take a default value (0.94 volt) instead of the input value.</li> </ul>
22	TC 22: THROTTLE POSIT. SENSOR VOLTAGE LOW	05	<ul style="list-style-type: none"> <li>o TPS signal voltage is less than 0.1 volt.</li> <li>• If the condition for code 22 exists the system will take a default value (0.94 volt) instead of input value.</li> </ul>
23	TC 23: MAT SENSOR VOLTAGE LOW	08	<ul style="list-style-type: none"> <li>o Engine has been running longer than 3 minutes at idle and MAT signal voltage indicated an intake air temperature below -30°C (-22°F). Vehicle is not moving. Above conditions are present for more than 1 second.</li> <li>OR</li> <li>o MAT signal voltage indicated an intake air temperature below -30°C (-22°F) and an engine temperature (CTS) above 60°C (140°F) and the engine is not running.</li> <li>• If the condition for code 23 exists the system will take a default value 4°C (39°F) instead of input value.</li> </ul>

**Table 2, Trouble Code Table**

Trouble Code	Information sensor Cause of Fault	Remedy in P0:DATA L. Test Step	Trouble Code Storage when ...
24	TC 24: NO VEHICLE SPEED SIGNAL	36	<ul style="list-style-type: none"> <li>o Engine running</li> <li>No MALF CODE 21 or 22</li> <li>Throttle position is less than 2%</li> <li>MAP load less than 25.0 KPa (z.B. deceleration with fuel cut off)</li> <li>Engine speed between 900 and 4400 RPM</li> <li>Vehicle speed less than or equal to 5 km/h (3 MPH)</li> <li>Above conditions present for more than 2 seconds</li> </ul> <ul style="list-style-type: none"> <li>• If code 24 exists the system will disable the closed loop conditions for idle run mode.</li> <li>In this case, the idle speed will be higher than normal.</li> </ul>
25	TC 25: MAP SENSOR VOLTAGE HIGH	08	<ul style="list-style-type: none"> <li>o Engine has been running longer than 1 minutes at idle and MAP signal voltage indicated an intake air temperature above 150°C (302°F). Vehicle is not moving. Above conditions are present for more than 3 second.</li> <li>or</li> <li>o Engine has been running longer than 1 minutes and MAP signal voltage indicated an intake air temperature above 150°C (302°F) and vehicle speed is greater than 8 km/h (5 MPH).</li> <li>Above conditions are present for more than 3 second.</li> </ul> <ul style="list-style-type: none"> <li>• If the condition for code 25 exists the system will take a default value 4°C (39°F) instead of the input value.</li> </ul>

**Table 2, Trouble Code Table**

Trouble Code	Information sensor Cause of Fault	Remedy in P0:DATA L. Test Step	Trouble Code Storage when ...
31	TC 31: CAMSHAFT SPEED SENSOR SIGNAL	37	<ul style="list-style-type: none"> <li>o Engine cranks and camshaft signal is missing</li> <li>o Engine is in run mode and camshaft signal is missing for a time greater than 180 seconds.</li> <li>or</li> <li>o Engine is in run mode and camshaft signal sensor registered more signals than possible. Time &gt; 1 second.</li> <li>o If the condition for code 31 exists the system will lose the synchronisation for proper sequencing of the fuel injectors. System remains in sequential mode but without synchronisation.</li> </ul>
33	TC 33: MAP SENSOR VOLTAGE HIGH	09	<ul style="list-style-type: none"> <li>o Engine running and fuel cut off activated for a time greater than 3 sec. and MAP sensor indicated a pressure &gt;190 kPa.</li> <li>or</li> <li>o Engine running. MALF CODE 21 or 22 are not set. MAP sensor indicated a pressure &gt;190 kPa and TPS sensor indicated a position less than 3% for more than 0.4 sec.</li> <li>o If the condition for code 33 exists the system will take a default value depending on the engine speed and TPS.</li> </ul>
34	TC 34: MAP SENSOR VOLTAGE LOW	09	<ul style="list-style-type: none"> <li>o Engine running. MALF CODE 21 are not set. MAP sensor indicated a pressure &lt; 20 kPa and TPS sensor indicated a position greater than 20% or engine speed is less than 700 RPM for more than 0.44 sec.</li> <li>o If the condition for code 34 exists the system will take a default value depending on the engine speed and TPS.</li> </ul>

**Table 2, Trouble Code Table**

Trouble Code	Information sensor Cause of Fault	Remedy In P0:DATA L. Test Step	Trouble Code Storage when ...
41	TC 41: CYLINDER SELECT ERROR; REPLACE PROM		<ul style="list-style-type: none"> <li>o ECM detected a mismatch between the calibrated numbers of fuel injectors and the real existent fuel injector CKT's for this engine.</li> <li>. See test step 03 or replace PROM/HEMICAL</li> </ul>
42	TC 42: BYPASS OR EST LINE FAIL	38	<ul style="list-style-type: none"> <li>o ECM had not seen a EST-pulse by EST monitor for more than 0.2 seconds. Engine speed greater than 450 RPM. or</li> <li>o Engine cranking less than 450 RPM. Bypass mode enabled. No EST-pulse seen by ECM. EST line may be open or shorted to ground.</li> </ul>
43	TC 43: KNOCK SENSOR CIRCUIT	11 12 13	<ul style="list-style-type: none"> <li>o the CT-sensor registered a engine temperature greater than 75°C (151°F) AND</li> <li>. BCM had seen a sensor voltage greater than 4.51 volt on knock sensor input (J2-B20) for more than 0.2 sec. or</li> <li>. BCM had seen a sensor voltage less than 0.65 volt on knock sensor input (J2-B20) for more than 0.2 sec.</li> <li>. The MALF CODE is cleared if the BCM detects an knock signal under normal conditions.</li> </ul>

**Table 2, Trouble Code Table**

Trouble Code	Information sensor Cause of Fault	Remedy in P0:DATA L. Test Step	Trouble Code Storage when ...
44	TC 44: FRONT O2 SENSOR LEAN EXHAUST	19 23 24 27 28	<p>Trouble Code Storage when ...</p> <p>In the discussion below the "front part" of engine refer to cylinders Nr. 1, 2, and 3 and the corresponding (front) O2-sensor and O2-integrator.</p> <ul style="list-style-type: none"> <li>o The front oxygen (O2) sensor signal is less than 0.2 volt for more than 2 minutes and the O2 front Integrator is not forced to 128.</li> <li>o If the condition for code 44 exists the system will not go "Closed Loop" in the "front part" of the engine.</li> </ul>
45	TC 45: FRONT O2 SENSOR RICH EXHAUST	19 23 24 27 28	<p>In the discussion below the "front part" of engine refer to cylinders Nr. 1, 2, and 3 and the corresponding (front) O2-sensor and O2-integrator.</p> <ul style="list-style-type: none"> <li>o The front oxygen (O2) sensor signal is greater than 0.75 volt for more than 30 seconds. The O2 front Integrator is not forced to 128 and the TPS sensor is greater than 20% or less than 2.7%.</li> <li>o If the condition for code 45 exists the system will not go "Closed Loop" in the "front part" of the engine.</li> </ul>
51	TC 51: REPLACE ECM OR PROM/MEMCAL		<ul style="list-style-type: none"> <li>o ECM is not able to read correct data from the calibration PROM/MEMCAL.</li> <li>o Remove and re-install PROM/MEMCAL. Ensuring that latches secured properly. Clear codes. If code resets, replace PROM/MEMCAL and retest. If code still resets, replace ECM.</li> </ul>

Table 2, Trouble Code Table

Trouble Code	Information sensor Cause of Fault	Remedy In P0:DATA L. Test Step	Trouble Code Storage when ...
53	TC 53: BATTERY VOLTAGE HIGH	01	<ul style="list-style-type: none"> <li>o ECM detects a battery voltage greater or equal than 17.1 volt.</li> <li>. All outputs are turned off to protect the hardware.</li> </ul>
63	TC 63: REAR O2 SENSOR OPEN CIRCUIT	20 25	<ul style="list-style-type: none"> <li>o O2 Signal voltage steady between 350 und 550 mV</li> <li>o Engine has been running longer than 2 minutes.</li> <li>o Engine coolant temperature greater than 69.5°C (158°F)</li> <li>o Throttle position sensor signal has been above 5% for 60 seconds or longer.</li> <li>. If the condition for code 63 exist the system will not go "Closed Loop" in the "rear part" of the engine.</li> </ul>
64	TC 64: REAR O2 SENSOR LEAN EXHAUST	20 25 26 27 28	<ul style="list-style-type: none"> <li>o In the discussion below the "rear part" of engine refer to cylinders Nr. 4, 5, and 6 and the corresponding (rear) O2-sensor.</li> <li>o The rear oxygen (O2) sensor signal is less than 0.2 volt for more than 2 minutes and the O2 rear Integrator is not forced to 128.</li> <li>. If the condition for code 64 exists the system will not go "Closed Loop" in the "rear part" of the engine.</li> </ul>



**Table 2, Trouble Code Table**

Trouble Code	Information sensor Cause of Fault	Remedy In P0:DATA L. Test Step	Trouble Code Storage when ...
65	TC 65: RRAR 02 SENSOR RICH EXHAUST	20 25 26 27 28	<p>In the discussion below the "rear part" of engine refer to cylinders Nr. 4, 5, and 6 and the corresponding (rear) 02-sensor.</p> <ul style="list-style-type: none"> <li>o The rear oxygen (O2) sensor signal is greater than 0.75 volt for more than 30 seconds. The O2 rear Integrator is not forced to 128 and the TPS sensor is greater than 20% or less than 2.7%.</li> <li>o If the condition for code 65 exists the system will not go "Closed Loop" in the "rear part" of the engine.</li> </ul>
66	TC 66: BOOST SYSTEM OUT OF LIMITS	09 16 17 18	<ul style="list-style-type: none"> <li>o RPM greater than 2700 RPM and learning duty cycle of the waste gate solenoid is less or equal than -49.6% or</li> <li>o RPM greater than 2700 RPM and learning duty cycle of the waste gate solenoid is greater or equal than +49.6%</li> </ul> <p>Note: The learning duty circle is equal to the WASTR GATR BIM.</p> <p>Repair system :See test step 09 and 17 part 2 System info. :See test step 16 and 19</p>

**4.7 Table 3, Part Numbers**

<b>MERCAL ID CODE</b>	<b>: 65 535</b>	
<b>BCM - Part</b>	<b>No. : P 530.417</b>	<b>657AF</b>
<b>Catalytic Converter No:</b>	<b>left</b>	<b>right</b>
	<b>P 530.4501 862A</b>	<b>P 530.4501 861A</b>

4.8 Table 4, Instructions for "Engine Does Not Start, Data Transfer OK"

If the TRCH 1 receives data from the control unit (ECM), no trouble code is stored, but engine does not start, the necessary tests are outlined in Table 4.

o follow further directions:

- |     |                             |      |                             |
|-----|-----------------------------|------|-----------------------------|
| 1)  | Battery                     | OK ? | . See test step 01          |
| 2)  | Fuel Pump                   | OK ? | . See test step 02          |
| 3)  | Starter                     |      |                             |
| 4)  | Compression                 |      |                             |
| 5)  | MODE P4: ACTUATOR TRST      |      |                             |
|     | Submode P0 .. P4            | OK ? | . Repair system             |
| 6)  | Fuel pressure               | OK ? |                             |
| 7)  | Injectors                   | OK ? | . See test step 14 and 15   |
| 8)  | Engine speed signal         | OK ? | . See test step 03          |
| 9)  | Primary voltage             | OK ? |                             |
| 10) | Secondary voltage           | OK ? |                             |
| 11) | Leakage in intake manifold  |      |                             |
| 12) | Restricted exhaust gas flow |      | . Check catalytic converter |

4.9 Table 5, P5: ACTUATOR TEST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
01	FAN STATUS COOLANT TEMP.	Engine OFF Ignition ON TECH 1 Submode: F0: FAN RELAY Press 'Up' arrow key	ACTIVE ON 5 sec. later OFF ... °F(C)    ... V	
<p><b>Trouble-shooting:</b></p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p>				
<p>o See test step 32</p>				
Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
02	A/C CLUTCH A/C REQUEST SW.	Engine OFF Ignition ON TECH 1 Submode: F1: A/C RELAY Press 'Up' arrow key	DISENGAGED ON 5 sec. later OFF OFF 0 V	
<p><b>Trouble-shooting:</b></p> <p>Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o See test step 33, 34</p>				

4.9 Table 5, P5: ACTUATOR TEST

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
03	CANISTER PURGE ENGINE SPEED	Engine OFF Ignition ON TECH 1 Submode: P2: CCP VALVE Press 'UP' arrow key	..... & 5 sec. later OFF ..... RPM	
<p><b>Trouble-shooting:</b> Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o See test step 31</p>				
Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
04	WASTE GATE FUNCT WASTE GATE D.C.	Engine OFF Ignition ON TECH 1 Submode: P3: WASTE GATE Press 'UP' arrow key	ENABLED ON 5 sec. later OFF 60 &	16, 66
<p><b>Trouble-shooting:</b> Nominal Value: Cause of Fault: (If nominal values NOT attained)</p> <p>o See test step 16, 17 and 18</p>				



4.10 Table 7, P7: ECM RESET

Test Step	TECH 1 - Display	Notes	Nominal Values	Possible Trouble Codes
01	RESET IAC MOTOR : RESET	Ignition ON Engine at Idle speed TECH 1 Submode: P0: IAC MOTOR Press "YES" key	ENGINE SPEED ... RPM IDLR AIR CONTROL ... STEPS ___ IAC ___ RST	

Trouble-shooting:

Nominal Value: Cause of Fault:  
 (If nominal values NOT attained)

If the Submode: P0: IAC MOTOR is enabled, the ECM will control the IAC MOTOR to find the correct position. The IAC MOTOR will move to the closed position. The ECM will further accept this position as "0 STEPS". After reset, the IAC MOTOR will move to a position who allow the engine to run on idle speed.

o See test step 06






**5 Terminal Assignment**


**5.1 Terminal Assignment in Diagnostic Plug X 130**

**A - Ground**  
**B - Diagnostic excitation lead for engine electronics**

**F - Battery voltage (Ter.30)**  
**G - Bidirectional Data lead**




D 2157




D 2163

### 5.2 Terminal Assignment Oxygen sensor plug

- A - Signal line to ECM
- B - Oxygen Sensor heater line to 12 V
- C - Signal line to ground (ECM pin J1-A21 and J3-C20)
- D - Oxygen Sensor heater line to GND




D 2167



D 2168

### 5.3 Terminal Assignment DI-Module


- A - DI-Module ground
- B - DI-Module to DIS\_FUSE (7.5 AMP) and Ignition Power Relay
- A - Line to Crank-Sensor, color "RG", twisted pair
- B - not used
- C - Line to Crank-Sensor, color "YR", twisted pair
- A - BYPASS line to BCM J4-D1
- B - RST line to BCM J4-D12
- C - Tacho out to interface connector 2
- D - not used
- E - RKP line to BCM J4-D18 "high"
- F - RKF line to BCM J4-D13 "low"



D 2165


5.4 Terminal Assignment ECM "J1"

J1-A1	Injector "6" line
J1-A2	Injector "5" line
J1-A3	Injector "1" line
J1-A4	IAC stepper motor line "A"
J1-A5	IAC stepper motor line "C"
J1-A6	Vehicle Speed Sensor line "B"
J1-A7	Injector "3" line
J1-A8	Injector "4" line
J1-A9	IAC stepper motor line "B"
J1-A10	IAC stepper motor line "D"
J1-A11	Vehicle Speed Sensor line "A"
J1-A12	Injector "2" line
J1-A13	--
J1-A14	--
J1-A15	A/C Control Switch (color BW)
J1-A16	Right Oxygen Sensor line "A" (input)
J1-A17	To interface connector Speedometer
J1-A18	--
J1-A19	Line to Fuel Pump Relay Ter. "6" (color OP)
J1-A20	--
J1-A21	Left Oxygen Sensor signal line "GROUND"
J1-A22	Line to Servotronic Electronic Module (color RY)
J1-A23	--
J1-A24	--




5.5 Terminal Assignment ECM "J2"

J2-B1	--	
J2-B2	Line to AIDL-Connector "B" (excitation lead)	
J2-B3	Throttle Position Sensor line "2" (input)	
J2-B4	MAP-Sensor line "B" (input)	
J2-B5	ECM output +5 Volt to MAP, Baro- and TP-Sensor	
J2-B6	ECM-Sensor Ground	
J2-B7	--	
J2-B8	ECM Voltage Supply	
J2-B9	Coolant Temperature Sensor line "A" (input)	
J2-B10	ECM Voltage Supply	
J2-B11	ECM Voltage Supply (long-term memory)	
J2-B12	Baro-Sensor line "B" (input)	
J2-B13	--	
J2-B14	--	
J2-B15	--	
J2-B16	ECM output GROUND to Baro-, TP- and CT-Sensor	
J2-B17	ECM POWER GROUND	
J2-B18	--	
J2-B19	--	
J2-B20	Electronic Spark Control Knock Sensor line (input)	
J2-B21	Manifold air temperature Sensor line "A" (input)	
J2-B22	--	
J2-B23	--	
J2-B24	--	




5.6 Terminal Assignment BCM "J3"

J3-C1	---	
J3-C2	---	
J3-C3	---	
J3-C4	---	
J3-C5	---	Line to HOT SOAK PUMP Relay coil (color OS)
J3-C6	---	Line to A/C - Interface conn. RAD FAN Relay coil
J3-C7	---	Line to A/C - Interface conn. A/C control switch
J3-C8	---	Only GND when A/C is not fitted.
J3-C9	---	
J3-C10	---	TO CHARCOAL CANNISTER PURGE SOLENOID
J3-C11	---	To interface conn. CHECK ENGINE LIGHT (color BLG)
J3-C12	---	BCM-POWER GROUND REDUNDANT
J3-C13	---	
J3-C14	---	
J3-C15	---	Left Oxygen Sensor line "A" (Input)
J3-C16	---	BCM output to A/C-Clutch Relay (color LGM)
J3-C17	---	
J3-C18	---	
J3-C19	---	
J3-C20	---	Right Oxygen Sensor line "GROUND"
J3-C21	---	
J3-C22	---	
J3-C23	---	
J3-C24	---	



5.7 Terminal Assignment ECM "J4"

J4-D1	BYPASS line to DI-Module
J4-D2	---
J4-D3	CAM Sensor Input (color NW)
J4-D4	---
J4-D5	---
J4-D6	---
J4-D7	---
J4-D8	---
J4-D9	---
J4-D10	To WASTE GATE SOLENOID
J4-D11	---
J4-D12	EST-Line to DI-Module
J4-D13	RFP-Line to DI-Module "low"
J4-D14	---
J4-D15	Line to ALDL-Connector "G" (bidirectional data lead)
J4-D16	---
J4-D17	---
J4-D18	RFP-Line to DI-Module "high"
J4-D19	---
J4-D20	---
J4-D21	---
J4-D22	---
J4-D23	---
J4-D24	---



6 Circuit Diagram  
6.1 Circuit Diagram LOTUS OMEGA


CON 2	=	Interface Connector 2 (Tacho)	P 23	=	MAP-Sensor = Manifold Absolute Pressure
X7 Ter."B"	=	A/C Interface Connector (Control Switch)	P 24	=	BARO-Sensor = Barometric Pressure Sensor
X7 Ter."C"	=	A/C Interface Connector (Not used)	P 30	=	MAT-Sensor = Mass Air Temperature
X7 Ter."F"	=	A/C Interface Connector (Rad Fan Coil)	P 31	=	CT -Sensor = Coolant Temperature Sensor
CON 4 "1"	=	Servo-tronic Electronic Module Line	P 34	=	TPS-Sensor = Throttle Position Sensor
FAN	=	FAN (Controlled by ECM)	P 35	=	Magnetic Vehicle Speed Sensor
PL 1	=	Maxi Fuse 50 Ampere	P 46	=	Knock Sensor
PLA	=	Fuel Pump /Injectors Relay Fuse 20 Amp.	P 47	=	CAM-Sensor
PLX	=	A/C Fuse 10 Ampere	S 1	=	Ignition Switch
PLZ	=	02 / CAM-Sensor fuse	S 2	=	Idle Pressure Switch (H.P.Line)
G 1	=	Battery	S 3	=	H.P. Cut Out Switch (A/C Comp.)
G 2	=	Alternator	S 4	=	L.P. Cut Out Switch (H.P. Line)
K 3	=	Theft Deterant Relay	S 5	=	High Pressure Switch (A/C Compressor)
K 31	=	Fuel Pump Relay	X 130	=	ALDL-Connector Engine
K 32	=	Ignition Power Relay	Y 34	=	Waste Gate Solenoid
K 35	=	A/C Clutch Relay	Y 35	=	Charcoal Canister Purge Solenoid
K 58	=	Hot Soak Pump Relay	Y 36	=	Hot Soak Pump Solenoid
K 202	=	Servo-tronic Electronic Module	Y 37	=	A/C Clutch
K 203	=	Electronic Hydr. Transducer			
K 204	=	Fan Relay			
K 222	=	ECM = Electronic Control Modul			
L 1	=	Oxygen Sensor Left			
L 2	=	Oxygen Sensor Right			
M 1	=	Starter			
M 21	=	Fuel Pump			
M 22	=	Hot Soak Water Pump			
M 33	=	IAC Motor = Idle Air Control Valve			



6 Circuit Diagram LOTUS OMEGA

TACHO	= Interface Connector (Tacho)	M 1	= Starter
X7 Tcr."B"	= A/C Interface Connector (Control Switch)	M 21	= Fuel Pump
X7 Tcr."C"	= A/C Interface Connector (Not used)	M 22	= Hot Soak Water Pump
X7 Tcr."F"	= A/C Interface Connector (Rad Fan Coil)	M 33	= IAC Motor = Idle Air Control Valve
CON 4	= Servotronic Electronic Module Line	P 23	= MAP-Sensor = Manifold Absolute Pressure
FAN	= FAN (Controlled by ECM)	P 24	= BARO-Sensor = Barometric Pressure Sensor
FL 1	= Maxi Fuse 50 Amp.	P 30	= MAT-Sensor = Mass Air Temperature
FLA.	= Fuel Pump /Injectors Relay Fuse 20 Amp.	P 31	= CT -Sensor = Coolant Temperature Sensor
FLX	= A/C Fuse 10 Amp.	P 34	= TPS-Sensor = Throttle Position Sensor
FLZ	= 02 / CAM-Sensor Fuse	P 35	= Magnetic Vehicle Speed Sensor
G 1	= Battery	P 46	= Knock Sensor
G 2	= Alternator	P 47	= CAM-Sensor
K 3	= Theft Deterant Relay	S 1	= Ignition Switch
K 6	= Engine Run Relay	S 2	= Idle Pressure Switch (H.P. Line)
K 7	= A/C Clutch Relay	S 3	= H.P. Cut Out Switch (A/C Comp.)
K 31	= Fuel Pump Relay	S 4	= L.P. Cut Out Switch (H.P. Line)
K 32	= Ignition Power Relay	S 5	= High Pressure Switch (A/C Compressor)
K 58	= Hot Soak Pump Relay	X 130	= ALDL-Connector Engine
K 202	= Servotronic Electronic Module	Y 34	= Waste Gate Solenoid
K 203	= Electronic Hydr. Transducer	Y 35	= Charcoal Canister Purge Solenoid
K 204 (K51)	= Fan Relay	Y 36	= Hot Soak Pump Solenoid
K 222	= ECM = Electronic Control Modul	Y 37	= A/C Clutch
L 1	= Oxygen Sensor Left		
L 2	= Oxygen Sensor Right		

# 6.1 Circuit Diagram LOTUS CARLTON



**LOTUS - OMEGA / CARLTON TRAINING**

